TABLE OF CONTENTS

Water-to-Air Heat Exchanger Products	2-4
Pumps and Pump Accessories	5
PEX Pipe, Fittings and Related	6
ThermoPEX, Central Therm, Manifolds and Water-to-Water Exchangers	
Water-to-Water Exchangers	8
Solder and Flux, Connections	9
Valves, Manifolds, Strainers, Connections, Adapters	10
Thermostats, Transformers, Aquastats	11
Baseboards, Copper Connections	
Push-fit Fittings	
Maintenance, Replacement and Optional Products	14
Maintenance, Replacement and Optional Products - Classic and Pallet Burner	15
Maintenance, Replacement and Options Products - E-Classic	16
Chimney Components - Classic, E-Classic and Pallet Burner	17
Maintenance, Replacement and Optional Products - Maxim	18-19
Chimney Components - Maxim	20-21
NUMERICAL PARTS LIST	22-23
SAMPLE PARTS LIST and ORDER LIST	

NOTE

All installations must be performed by a qualified installer and in accordance with any and all federal, state/provincial and local codes and regulations. When performing work on an appliance observe all precautions in the literature, tags and labels attached to the appliance and other safety precautions that may apply. When working with electricity and electrical components, failure to follow precautions could result in property damage, personal injury or death.

ALPHABETICAL INDEX


	Ga
1-1/4" Thermostatic Valve Kit	Gr
2-Way Zone Valve, 24-Volt	Gu
3/4" Thermostatic Valve Kit	He
3/8" Cleaning Rod	He
	He
3-Way Valve	He
6" Chimney Band Clamp Kit	He
6" Chimney Cap	He
8" Chimney Band Clamp Kit17	He
8" Chimney Base Brace Kit	He
8" Chimney Guy-Wire Band Kit	He
24-Volt Transformer	He
45° Street Elbow9	He
48-Bushel Hopper Kit	Hiç
90° Elbow, Copper	Ho
90° Reducing Elbow, Copper	Ho
90° Street Elbow9	Ho
90° Street Elbow, 1" Copper	Ho
Aerator	Inc
Air Handler Cabinet3	Isc
Ash Rake	Isc
Ash Scoop	Kid
Ash Shovel	Lin
Ashtrol	Lir
Attic Radiation Shield	Lo
Automatic Vent Valve	Ma
Auxiliary Auger Kits for Maxim	Ma
Packflow Proventor	Ma
Backflow Preventer	Ma
Bag Holder Kit	Ma Ma
Ball Valve	Ma
Baseboard Corners 12	Mo
Baseboard Corners	Mu
Baseboard Joiner	Na
	Nip
Blower & Motor	0-
Brass Coupling	Pa
Brass Hex Bushing	PE
Brass Hose Bib	PE
Rrace Officat Tag //"	PE
Brass Offset Tee, 4" 9 Brass Pipe Union, FIP 9	PE
Brass Swing Check Valve	PE
Brass Tee, 3/4"	PE
Cast Iron Manifold 10	PE
Cast Iron Manifold	PE
Central PEX 1/2" Pipe	PE
Central PEX 1" Pipe	PE
Central PEX 1" Pipe Sections	Pip
Central Therm Insulation	
0 / 17 0	Pla
Central Therm Sleeve	
Central Therm Sleeve	Pla
	Pla Plu Po
Central Therm Sleeve Dispenser	Pla Plu Po
Central Therm Sleeve Dispenser .7 Chimney Attachment Ring .17, 21 Chimney Components .17 Chimney Elbow .20	Pla Plu Po Po
Central Therm Sleeve Dispenser .7 Chimney Attachment Ring .17, 21 Chimney Components .17 Chimney Elbow .20 Chimney Support Brace Kit .17	Pla Plu Po Po Pro
Central Therm Sleeve Dispenser .7 Chimney Attachment Ring .17, 21 Chimney Components .17 Chimney Elbow .20	Pla Plu Po Pro Pro
Central Therm Sleeve Dispenser 7 Chimney Attachment Ring 17, 21 Chimney Components 17 Chimney Elbow 20 Chimney Support Brace Kit 17 Chimney Tee Restrictor Kit 17 Cinch Tool 6	Pla Plu Po Pro Pro Pu Pu
Central Therm Sleeve Dispenser .7 Chimney Attachment Ring .17, 21 Chimney Components .17 Chimney Elbow .20 Chimney Support Brace Kit .17 Chimney Tee Restrictor Kit .17 Cinch Tool .6 Clamp Crimp Ring Removal Tool .6	Pla Plu Po Pro Pro Pu Pu Pu
Central Therm Sleeve Dispenser .7 Chimney Attachment Ring .17, 21 Chimney Components .17 Chimney Elbow .20 Chimney Support Brace Kit .17 Chimney Tee Restrictor Kit .17 Cinch Tool .6 Clamp Crimp Ring Removal Tool .6 Classic Stainless Steel Chimney Sections .17	Pla Plu Po Pro Pro Pu Pu Pu
Central Therm Sleeve Dispenser .7 Chimney Attachment Ring .17, 21 Chimney Components .17 Chimney Elbow .20 Chimney Support Brace Kit .17 Chimney Tee Restrictor Kit .17 Cinch Tool .6 Clamp Crimp Ring Removal Tool .6 Classic Stainless Steel Chimney Sections .17 Cleaning Brush .9	Pla Plu Po Pro Pro Pu Pu Pu Pu
Central Therm Sleeve Dispenser 7 Chimney Attachment Ring 17, 21 Chimney Components 17 Chimney Elbow 20 Chimney Support Brace Kit 17 Chimney Tee Restrictor Kit 17 Cinch Tool 6 Clamp Crimp Ring Removal Tool 6 Classic Stainless Steel Chimney Sections 17 Cleaning Brush 9 Cleaning Rod 16	Pla Plu Po Pro Pro Pu Pu Pu Ra
Central Therm Sleeve Dispenser 7 Chimney Attachment Ring 17, 21 Chimney Components 17 Chimney Elbow 20 Chimney Support Brace Kit 17 Chimney Tee Restrictor Kit 17 Cinch Tool 6 Clamp Crimp Ring Removal Tool 6 Classic Stainless Steel Chimney Sections 17 Cleaning Brush 9 Cleaning Rod 16 Connector, Straight 13	Pla Plu Po Pro Pu Pu Pu Ra Ra
Central Therm Sleeve Dispenser 7 Chimney Attachment Ring 17, 21 Chimney Components 17 Chimney Elbow 20 Chimney Support Brace Kit 17 Chimney Tee Restrictor Kit 17 Cinch Tool 6 Clamp Crimp Ring Removal Tool 6 Classic Stainless Steel Chimney Sections 17 Cleaning Brush 9 Cleaning Rod 16 Connector, Straight 13 Copper Coupling 12	Pla Plu Po Pro Pro Pu Pu Pu Ra Ra Re
Central Therm Sleeve Dispenser 7 Chimney Attachment Ring 17, 21 Chimney Components 17 Chimney Elbow 20 Chimney Support Brace Kit 17 Chimney Tee Restrictor Kit 17 Cinch Tool 6 Clamp Crimp Ring Removal Tool 6 Classic Stainless Steel Chimney Sections 17 Cleaning Brush 9 Cleaning Rod 16 Conpector, Straight 13 Copper Coupling 12 Cooper End Cap 12	Pla Plu Po Pro Pro Pu Pu Pu Ra Ra Re Re
Central Therm Sleeve Dispenser 7 Chimney Attachment Ring 17, 21 Chimney Components 17 Chimney Elbow 20 Chimney Support Brace Kit 17 Chimney Tee Restrictor Kit 17 Cinch Tool 6 Clamp Crimp Ring Removal Tool 6 Classic Stainless Steel Chimney Sections 17 Cleaning Brush 9 Cleaning Rod 16 Connector, Straight 13 Copper Coupling 12 Copper End Cap 12 Corner Fan Convector (7k Btu) 3	Pla Plu Po Pro Pro Pu Pu Pu Ra Ra Re Re Re
Central Therm Sleeve Dispenser 7 Chimney Attachment Ring 17, 21 Chimney Components 17 Chimney Elbow 20 Chimney Support Brace Kit 17 Chimney Tee Restrictor Kit 17 Cinch Tool 6 Clamp Crimp Ring Removal Tool 6 Classic Stainless Steel Chimney Sections 17 Cleaning Brush 9 Cleaning Rod 16 Connector, Straight 13 Copper Coupling 12 Copper End Cap 12 Corner Fan Convector (7k Btu) 3 Corrosion Inhibitor Plus 14	Pla Plu Po Pro Pro Pu Pu Pu Ra Re Re Re Re Ro Ro
Central Therm Sleeve Dispenser .7 Chimmey Attachment Ring .17, 21 Chimney Components .17 Chimney Elbow .20 Chimney Support Brace Kit .17 Chimney Tee Restrictor Kit .17 Cinch Tool .6 Clamp Crimp Ring Removal Tool .6 Classic Stainless Steel Chimney Sections .17 Cleaning Brush .9 Cleaning Rod .16 Connector, Straight .13 Copper Coupling .12 Copper End Cap .12 Corresion Inhibitor Plus .3 Corrosion Inhibitor Plus .14 Coupling, Reducing .13	Pla Plu Po Pro Pu Pu Pu Ra Re Re Ro Sir
Central Therm Sleeve Dispenser 7 Chimney Attachment Ring 17, 21 Chimney Components 17 Chimney Elbow. 20 Chimney Support Brace Kit 17 Chimney Tee Restrictor Kit. 17 Cinch Tool. 6 Clamp Crimp Ring Removal Tool 6 Classic Stainless Steel Chimney Sections 17 Cleaning Brush 9 Cleaning Rod 16 Connector, Straight 13 Copper Coupling 12 Copper End Cap 12 Corner Fan Convector (7k Btu) 3 Corrosion Inhibitor Plus 14 Coupling, Reducing 13 Coupling, Straight 13	Pla Plu Po Pro Pu Pu Pu Ra Re Re Re Siri Slu
Central Therm Sleeve Dispenser 7 Chimney Attachment Ring 17, 21 Chimney Components 17 Chimney Elbow 20 Chimney Support Brace Kit 17 Chimney Tee Restrictor Kit 17 Cinch Tool 6 Clamp Crimp Ring Removal Tool 6 Classic Stainless Steel Chimney Sections 17 Cleaning Brush 9 Cleaning Rod 16 Connector, Straight 13 Copper Coupling 12 Copper End Cap 12 Corner Fan Convector (7k Btu) 3 Corrosion Inhibitor Plus 14 Coupling, Reducing 13 Coupling, Straight 13 Decoiler 14	Plane
Central Therm Sleeve Dispenser 7 Chimney Attachment Ring 17, 21 Chimney Components 17 Chimney Elbow 20 Chimney Support Brace Kit 17 Chimney Tee Restrictor Kit 17 Cinch Tool 6 Clamp Crimp Ring Removal Tool 6 Classic Stainless Steel Chimney Sections 17 Cleaning Brush 9 Cleaning Rod 16 Connector, Straight 13 Copper Coupling 12 Copper End Cap 12 Corner Fan Convector (7k Btu) 3 Corrosion Inhibitor Plus 14 Coupling, Reducing 13 Coupling, Straight 13 Decoiler 14 Depth Gauge/Deburring Tool 13	Plane
Central Therm Sleeve Dispenser .7 Chimmey Attachment Ring .17, 21 Chimney Components .17 Chimney Elbow .20 Chimney Support Brace Kit .17 Chimney Tee Restrictor Kit .17 Cinch Tool .6 Clamp Crimp Ring Removal Tool .6 Classic Stainless Steel Chimney Sections .17 Cleaning Brush .9 Cleaning Rod .16 Connector, Straight .13 Copper Coupling .12 Copper End Cap .12 Corresion Inhibitor Plus .14 Coupling, Reducing .13 Coupling, Straight .13 Deepth Gauge/Deburring Tool .13 Disconnect Clip .13	Plane Plu Pu Pu Pu Pu Pu Raa Ree Roo Siriu Soo Sp
Central Therm Sleeve Dispenser 7 Chimney Attachment Ring 17, 21 Chimney Components 17 Chimney Elbow 20 Chimney Support Brace Kit 17 Chimney Tee Restrictor Kit 17 Cinch Tool 6 Clamp Crimp Ring Removal Tool 6 Classic Stainless Steel Chimney Sections 17 Cleaning Brush 99 Cleaning Rod 16 Connector, Straight 13 Copper Coupling 12 Copper End Cap 12 Corner Fan Convector (7k Btu) 3 Corrosion Inhibitor Plus 14 Coupling, Reducing 13 Coupling, Straight 13 Decoiler 14 Depth Gauge/Deburring Tool 13 Disconnect Clip 13 Diverter Tee 9	Plane Plu Pu Pu Pu Pu Pu Pu Pu Raa Ree Reo Siris Soo Spp Sp
Central Therm Sleeve Dispenser 7 Chimney Attachment Ring 17, 21 Chimney Components 17 Chimney Elbow 20 Chimney Support Brace Kit 17 Chimney Tee Restrictor Kit 17 Cinch Tool 6 Clamp Crimp Ring Removal Tool 6 Classic Stainless Steel Chimney Sections 17 Cleaning Brush 9 Cleaning Rod 16 Connector, Straight 13 Copper Coupling 12 Copper End Cap 12 Corner Fan Convector (7k Btu) 3 Corrosion Inhibitor Plus 14 Coupling, Reducing 13 Coupling, Straight 13 Decoiler 14 Depth Gauge/Deburring Tool 13 Disconnect Clip 13 Diverter Tee 9 Door Lock Kit 15	Plane Pur
Central Therm Sleeve Dispenser 7 Chimney Attachment Ring 17, 21 Chimney Components 17 Chimney Elbow 20 Chimney Support Brace Kit 17 Chimney Tee Restrictor Kit 17 Cinch Tool 6 Clamp Crimp Ring Removal Tool 6 Classic Stainless Steel Chimney Sections 17 Cleaning Brush 9 Cleaning Rod 16 Connector, Straight 13 Copper Coupling 12 Copper End Cap 12 Corner Fan Convector (7k Btu) 3 Corrosion Inhibitor Plus 14 Coupling, Reducing 13 Coupling, Straight 13 Decoiler 14 Depth Gauge/Deburring Tool 13 Disconnect Clip 13 Diverter Tee 9 Door Lock Kit 15 Draft Inducer 15	Plane Pur
Central Therm Sleeve Dispenser 7 Chimney Attachment Ring 17, 21 Chimney Components 17 Chimney Elbow 20 Chimney Support Brace Kit 17 Chimney Tee Restrictor Kit 17 Cinch Tool 6 Clamp Crimp Ring Removal Tool 6 Classic Stainless Steel Chimney Sections 17 Cleaning Brush 19 Cleaning Rod 16 Connector, Straight 13 Copper Coupling 12 Copper End Cap 12 Corner Fan Convector (7k Btu) 3 Corrosion Inhibitor Plus 14 Coupling, Reducing 13 Coupling, Straight 13 Decoiler 14 Depth Gauge/Deburring Tool 13 Disconnect Clip 13 Diverter Tee 9 Door Lock Kit 15 Draft Inducer 15 Drair Coupling, Copper 12	Plane Pur Pur Pur Pur Pur Pur Pur Raa Ree Roisirio Son Son Son Son Son Son Son Son Son So
Central Therm Sleeve Dispenser 7 Chimney Attachment Ring 17, 21 Chimney Components 17 Chimney Elbow 20 Chimney Support Brace Kit 17 Chimney Tee Restrictor Kit 17 Cinch Tool 6 Clamp Crimp Ring Removal Tool 6 Classic Stainless Steel Chimney Sections 17 Cleaning Brush 9 Cleaning Rod 16 Connector, Straight 13 Copper Coupling 12 Copper End Cap 12 Corner Fan Convector (7k Btu) 3 Corrorsion Inhibitor Plus 14 Coupling, Reducing 13 Coupling, Straight 13 Decoiler 14 Depth Gauge/Deburring Tool 13 Disconnect Clip 13 Disconnect Clip 13 Diverter Tee 9 Door Lock Kit 15 Draft Inducer 15 Draft Inducer 15 Draft Coupling, Copper 12	Plane Por Property Purple Rate Ree Rosinis Son Spane Sun
Central Therm Sleeve Dispenser 7 Chimney Attachment Ring 17, 21 Chimney Components 17 Chimney Elbow 20 Chimney Support Brace Kit 17 Chimney Tee Restrictor Kit 17 Cinch Tool 6 Clamp Crimp Ring Removal Tool 6 Classic Stainless Steel Chimney Sections 17 Cleaning Brush 9 Cleaning Rod 16 Connector, Straight 13 Copper Coupling 12 Copper End Cap 12 Corner Fan Convector (7k Btu) 3 Corrosion Inhibitor Plus 14 Coupling, Reducing 13 Coupling, Straight 13 Decoiler 14 Depth Gauge/Deburring Tool 13 Diverter Tee 9 Door Lock Kit 15 Draft Inducer 15 Drain Coupling, Copper 12 E-Classic Stainless Steel Chimney Section 17 Elbow 13	Plate Plu Po
Central Therm Sleeve Dispenser 7 Chimney Attachment Ring 17, 21 Chimney Components 17 Chimney Elbow 20 Chimney Support Brace Kit 17 Chimney Tee Restrictor Kit 17 Cinch Tool 6 Clamp Crimp Ring Removal Tool 6 Classic Stainless Steel Chimney Sections 17 Cleaning Brush 9 Cleaning Rod 16 Connector, Straight 13 Copper Coupling 12 Copper End Cap 12 Corner Fan Convector (7k Btu) 3 Corrosion Inhibitor Plus 14 Coupling, Reducing 13 Coupling, Straight 13 Decoiler 14 Depth Gauge/Deburring Tool 13 Diverter Tee 9 Door Lock Kit 15 Draft Inducer 15 Drain Coupling, Copper 12 E-Classic Stainless Steel Chimney Section 17 Elbow 13	Plate Plu Po
Central Therm Sleeve Dispenser 7 Chimney Attachment Ring 17, 21 Chimney Components 17 Chimney Elbow 20 Chimney Support Brace Kit 17 Chimney Tee Restrictor Kit 17 Cinch Tool 6 Clamp Crimp Ring Removal Tool 6 Classic Stainless Steel Chimney Sections 17 Cleaning Brush 99 Cleaning Rod 16 Connector, Straight 13 Copper Coupling 12 Copper End Cap 12 Copper End Cap 12 Corner Fan Convector (7k Btu) 3 Corrosion Inhibitor Plus 14 Coupling, Reducing 13 Coupling, Straight 13 Disconnect Clip 13 Disconnect Clip 13 Disconnect Clip 13 Diverter Tee 9 Door Lock Kit 15 Draft Inducer 15 Drain Coupling, Copper 12 E-Classic Stainless Steel Chimney Section	Plate Plu Po
Central Therm Sleeve Dispenser 7 Chimney Attachment Ring 17, 21 Chimney Components 17 Chimney Elbow 20 Chimney Support Brace Kit 17 Chimney Tee Restrictor Kit 17 Cinch Tool 6 Clamp Crimp Ring Removal Tool 6 Classic Stainless Steel Chimney Sections 17 Cleaning Brush 99 Cleaning Rod 16 Connector, Straight 13 Copper Coupling 12 Copper End Cap 12 Copper End Cap 12 Corner Fan Convector (7k Btu) 3 Corrosion Inhibitor Plus 14 Coupling, Reducing 13 Coupling, Straight 13 Disconnect Clip 13 Disconnect Clip 13 Disconnect Clip 13 Diverter Tee 9 Door Lock Kit 15 Draft Inducer 15 Drain Coupling, Copper 12 E-Classic Stainless Steel Chimney Section	Pla Plu Pu Pu Pu Pu Ra Rae Reo Sirin So Spos Su
Central Therm Sleeve Dispenser 7 Chimney Attachment Ring 17, 21 Chimney Components 17, 21 Chimney Elbow 20 Chimney Support Brace Kit 17 Chimney Tee Restrictor Kit 17 Cinch Tool 6 Clamp Crimp Ring Removal Tool 6 Clamp Crimp Ring Removal Tool 6 Classic Stainless Steel Chimney Sections 17 Cleaning Brush 9 Cleaning Rod 16 Connector, Straight 13 Copper Coupling 12 Copper Coupling 12 Copper End Cap 12 Corner Fan Convector (7k Btu) 3 Corrorsion Inhibitor Plus 14 Coupling, Reducing 13 Coupling, Straight 13 Decoiler 14 Depth Gauge/Deburring Tool 13 Disconnect Clip 13 Diverter Tee 9 Door Lock Kit 15 Draft Inducer 15 Drain Coupling, Copper	Plate Pool Pool Pool Pool Pool Pool Pool Poo
Central Therm Sleeve Dispenser 7 Chimney Attachment Ring 17, 21 Chimney Components 17 Chimney Elbow. 20 Chimney Support Brace Kit 17 Chimney Tee Restrictor Kit. 17 Cinch Tool. 6 Clamp Crimp Ring Removal Tool 6 Clamp Crimp Ring Removal Tool 6 Classic Stainless Steel Chimney Sections 17 Cleaning Brush. 19 Cleaning Rod 16 Connector, Straight. 13 Copper Coupling. 12 Copper End Cap 12 Corner Fan Convector (7k Btu) 3 Corrier Fan Convector (7k Btu) 3 Corping, Reducing 13 Coupling, Reducing 13 Ouspling, Straight 13 Deciler 14 Depth Gauge/Deburring Tool 13 Disconnect Clip 13 Disconnect Clip 13 Diverter Tee 9 Door Lock Kit 15 Draft Inducer	Plate Plu Pu Pu Pu Pu Pu Raa Raa Raa Raa Raa Raa Siiri Soo Soo Soo Soo Soo Soo Soo Soo Soo So
Central Therm Sleeve Dispenser 7 Chimney Attachment Ring 17, 21 Chimney Components 17 Chimney Elbow 20 Chimney Support Brace Kit 17 Chimney Tee Restrictor Kit 17 Cinch Tool 6 Clamp Crimp Ring Removal Tool 6 Classic Stainless Steel Chimney Sections 17 Cleaning Brush 99 Cleaning Rod 16 Connector, Straight 13 Copper Coupling 12 Copper End Cap 12 Copper End Cap 12 Corner Fan Convector (7k Btu) 3 Corrosion Inhibitor Plus 14 Coupling, Reducing 13 Coupling, Reducing 13 Coupling, Straight 13 Disconnect Clip 13 Disconnect Clip 13 Disconnect Clip 13 Diverter Tee 9 Door Lock Kit 15 Draft Inducer 15 Drain Coupling, Copper 12	Plate Por Property Purply Purply Purply Purply Purply Purply Rate Reconstruction Science Scien
Central Therm Sleeve Dispenser 7 Chimney Attachment Ring 17, 21 Chimney Components 17 Chimney Elbow 20 Chimney Support Brace Kit 17 Chimney Tee Restrictor Kit 17 Cinch Tool 6 Clamp Crimp Ring Removal Tool 6 Clamp Crimp Ring Removal Tool 6 Classic Stainless Steel Chimney Sections 17 Cleaning Brush 9 Cleaning Rod 16 Connector, Straight 13 Copper Coupling 12 Copper Coupling 12 Copper End Cap 12 Corner Fan Convector (7k Btu) 3 Corrosion Inhibitor Plus 14 Coupling, Straight 13 Decoiler 14 Depth Gauge/Deburring Tool 13 Disconnect Clip 13 Diverter Tee 9 Door Lock Kit 15 Draft Inducer 15 Drain Coupling, Copper 15 E-Classic Stainless Steel Chimne	Plate Purple Pur
Central Therm Sleeve Dispenser 7 Chimney Attachment Ring 17, 21 Chimney Components 17, 21 Chimney Elbow 20 Chimney Support Brace Kit 17 Chimney Flee Restrictor Kit 17 Cinch Tool 6 Clamp Crimp Ring Removal Tool 6 Clamp Crimp Ring Removal Tool 6 Classic Stainless Steel Chimney Sections 17 Cleaning Brush 9 Cleaning Rod 16 Connector, Straight 13 Copper Coupling 12 Copper End Cap 12 Corner Fan Convector (7k Btu) 3 Corrosion Inhibitor Plus 14 Coupling, Reducing 13 Coupling, Straight 13 Decoiler 14 Depth Gauge/Deburring Tool 13 Disconnect Clip 13 Diverter Tee 9 Door Lock Kit 15 Draft Inducer 15 Drain Coupling, Copper 12 E-Classic Stainless Stee	Plate Pull Poor Print Pull Poor Print Pull Pull Pull Pull Pull Pull Pull Pul
Central Therm Sleeve Dispenser 7 Chimney Attachment Ring 17, 21 Chimney Components 17 Chimney Elbow 20 Chimney Support Brace Kit 17 Chimney Tee Restrictor Kit 17 Cinch Tool 6 Clamp Crimp Ring Removal Tool 6 Clamp Crimp Ring Removal Tool 6 Classic Stainless Steel Chimney Sections 17 Cleaning Brush 9 Cleaning Rod 16 Connector, Straight 13 Copper Coupling 12 Copper Coupling 12 Copper End Cap 12 Corner Fan Convector (7k Btu) 3 Corrosion Inhibitor Plus 14 Coupling, Straight 13 Decoiler 14 Depth Gauge/Deburring Tool 13 Disconnect Clip 13 Diverter Tee 9 Door Lock Kit 15 Draft Inducer 15 Drain Coupling, Copper 15 E-Classic Stainless Steel Chimne	Plain Plui Piul Poor Pru Puu Puu Puu Puu Puu Puu Puu Puu Pu
Central Therm Sleeve Dispenser 7 Chimney Attachment Ring 17, 21 Chimney Components 17 Chimney Elbow 20 Chimney Support Brace Kit 17 Chimney Tee Restrictor Kit 17 Cinch Tool 6 Clamp Crimp Ring Removal Tool 6 Clamp Crimp Ring Removal Tool 6 Clasning Brush 9 Cleaning Brush 17 Cleaning Rod 16 Connector, Straight 13 Copper Coupling 12 Copper End Cap 12 Corner Fan Convector (7k Btu) 3 Corrosion Inhibitor Plus 14 Coupling, Reducing 13 Coupling, Reducing 13 Coupling, Reducing 13 Disconnect Clip 13 Disconnect Clip 13 Disconnect Clip 13 Disconnect Clip 13 Diverter Tee 9 Door Lock Kit 15 Draft Inducer 15	Plate Plus Puu Puu Puu Puu Raa Ree Reo Siriis Soo Spps Suu Taa Taa Taa Taa Taa Taa Taa Taa Taa T
Central Therm Sleeve Dispenser 7 Chimney Attachment Ring 17, 21 Chimney Components 17 Chimney Elbow 20 Chimney Support Brace Kit 17 Chimney Tee Restrictor Kit 17 Cinch Tool 6 Clamp Crimp Ring Removal Tool 6 Clamp Crimp Ring Removal Tool 6 Claaning Brush 9 Cleaning Brush 9 Cleaning Rod 16 Connector, Straight 13 Copper Coupling 12 Copper End Cap 12 Corper Fan Convector (7k Btu) 3 Corrorsion Inhibitor Plus 14 Coupling, Reducing 13 Coupling, Reducing 13 Coupling, Straight 13 Disconnect Clip 13 Disconnect Clip 13 Disconnect Clip 13 Disconnect Clip 13 Diverter Tee 9 Door Lock Kit 15 Draft Inducer 15	Plal Plul Poor Pru Puu Puu Puu Puu Puu Puu Puu Puu Pu
Central Therm Sleeve Dispenser 7 Chimney Attachment Ring 17, 21 Chimney Components 17, 21 Chimney Elbow 20 Chimney Support Brace Kit 17 Chimney Tee Restrictor Kit 17 Cinch Tool 6 Clamp Crimp Ring Removal Tool 6 Clamp Crimp Ring Removal Tool 6 Claaning Brush 9 Cleaning Brush 9 Cleaning Rod 16 Connector, Straight 13 Copper Coupling 12 Copper Coupling 12 Copper End Cap 12 Corner Fan Convector (7k Btu) 3 Corrosion Inhibitor Plus 14 Coupling, Reducing 13 Coupling, Straight 13 Decoiler 14 Depth Gauge/Deburring Tool 13 Disconnect Clip 13 Diverter Tee 9 Door Lock Kit 15 Drain Coupling, Copper 12 E-Classic Stainless Steel Chimney Section	Plain Plu Puu Puu Puu Raa Ree Ree Ree Ree Sirii Taa Taa Taa Taa Taa Taa Taa Taa Taa T
Central Therm Sleeve Dispenser 7 Chimney Attachment Ring 17, 21 Chimney Components 17 Chimney Elbow. 20 Chimney Support Brace Kit 17 Chimney Tee Restrictor Kit. 17 Cinch Tool. 6 Clamp Crimp Ring Removal Tool 6 Clamp Crimp Ring Removal Tool 6 Classic Stainless Steel Chimney Sections 17 Cleaning Brush. 19 Cleaning Rod 16 Connector, Straight. 13 Copper Coupling 12 Copper End Cap 12 Corner Fan Convector (7k Btu) 3 Corrosion Inhibitor Plus 14 Coupling, Reducing 13 Coupling, Reducing 13 Ocupling, Reducing 13 Decoiler 14 Depth Gauge/Deburring Tool 13 Disconnect Clip. 13 Disconnect Clip. 13 Diverter Tee 9 Door Lock Kit 15 Draft Inducer	Plain Plu Puu Puu Puu Raa Ree Ree Ree Roos Sppp Suu Taa Taa Taa Taa Taa Taa Taa Taa Taa T

0 11 10 11	
Gas Hose w/Regulator	19
Grounding Rod Kit	
Guy-Wire Band.	21
Heat Exchanger Coil (50k Btu)	. 2
Heat Exchanger Coil (80k Btu)	. 2
Heat Exchanger Coil (95k Btu)	. 2
Heat Exchanger Coil (100k Btú)	.2
Heat Exchanger Coil (125k Btu)	.2
Heat Exchanger Coil (140k Btu)	. 2
Heat Exchanger Coil (220k Btu)	2
Heat Exchanger Mounting Kit.	8
HeatTrac Controller Update Kits.	
Hex Bushing	9
High Pressure Gas Hose Adapter	19
Hoe	15
Hopper Extension Kit	18
Hopper Vibrator Kit	
Hot Filter & Cartridge	10
Indoor Water Temperature Indicator Kit	14
Isolation Flange Kit	. 5
Isolation Flange with Drain Valve, 3/4"	. 5
Kickspace Fan Convector.	
Line Voltage Thermostat.	
Linkage	
Male Adapter, 3/4" Hose.	
Male Adapter, Copper.	
Manifold	
Manifold w/o Valves	
Manifold w/Valves	.7
Maxim Chimney Lengths	20
Maxim Stainless Steel Chimney Sections	20
Monoflo Copper Tee	. 9
Multi-stage 24-Volt Thermostat	
Natural Gas Conversion Kit	
Nipple	
O-Ring Set	
Panel Radiators	
PEX 1-1/4" Pipe	
PEX Adapter.	
PEX Brass Clamp Fittings	
PEX Coupling	6
PEX Crimp Rings / Crimp Tools	6
PEX Hanger	
PEX Pipe Cutter	6
PEX Pipe Cutter	6
PEX Tee	6
Dina Dlug	
Pipe Plug	9
Plate Heat Exchanger	9
Plate Heat Exchanger	9 7 7
Plate Heat Exchanger. Plate Mounting Bracket Plug-in Thermostat	9 7 7
Plate Heat Exchanger. Plate Mounting Bracket Plug-in Thermostat Pool Aquastat	9 7 7 11
Plate Heat Exchanger. Plate Mounting Bracket Plug-in Thermostat Pool Aquastat	9 7 7 11
Plate Heat Exchanger. Plate Mounting Bracket Plug-in Thermostat Pool Aquastat Power Supply Cord Programmable 24-Volt Thermostat.	.9 .7 11 11 .5
Plate Heat Exchanger. Plate Mounting Bracket Plug-in Thermostat Pool Aquastat Power Supply Cord. Programmable 24-Volt Thermostat. Propane Shut-off with Level Indicator.	9 7 11 11 5 11
Plate Heat Exchanger Plate Mounting Bracket Plug-in Thermostat Pool Aquastat Power Supply Cord. Programmable 24-Volt Thermostat. Propane Shut-off with Level Indicator. Pulse Timer Kit	9 7 11 11 5 11 19
Plate Heat Exchanger. Plate Mounting Bracket Plug-in Thermostat Pool Aquastat Power Supply Cord. Programmable 24-Volt Thermostat. Propane Shut-off with Level Indicator.	9 7 11 11 5 11 19 16
Plate Heat Exchanger Plate Mounting Bracket Plug-in Thermostat Pool Aquastat Power Supply Cord Propane Shut-off with Level Indicator. Pulse Timer Kit Pump Flange Kits Purging and Filling Tee Push-fit Fittings	9 7 11 11 5 11 19 16 5 10
Plate Heat Exchanger. Plate Mounting Bracket Plug-in Thermostat Pool Aquastat Power Supply Cord. Programmable 24-Volt Thermostat. Propane Shut-off with Level Indicator. Pulse Timer Kit. Pump Flange Kits. Purging and Filling Tee Push-fit Fittings. Push-fit Fittings Water Heater Kit.	9 7 11 11 15 11 19 16 5 10 13
Plate Heat Exchanger. Plate Mounting Bracket Plug-in Thermostat Pool Aquastat Power Supply Cord. Programmable 24-Volt Thermostat. Propane Shut-off with Level Indicator. Pulse Timer Kit Pump Flange Kits. Purging and Filling Tee Push-fit Fittings Push-fit Fittings Radiation Shield	9 7 7 11 11 15 11 19 16 16 13 13
Plate Heat Exchanger. Plate Mounting Bracket Plug-in Thermostat Pool Aquastat Power Supply Cord Programmable 24-Volt Thermostat. Propane Shut-off with Level Indicator. Pulse Timer Kit Pump Flange Kits Purging and Filling Tee Push-fit Fittings Push-fit Fittings Push-fit Fittings Water Heater Kit Radiation Shield Ratchet Cinch Tool	9 7 7 11 11 15 11 19 16 5 10 13 13 12 0
Plate Heat Exchanger Plate Mounting Bracket Plug-in Thermostat Pool Aquastat Power Supply Cord. Programmable 24-Volt Thermostat. Propane Shut-off with Level Indicator. Pulse Timer Kit Pump Flange Kits Purging and Filling Tee Push-fit Fittings Push-fit Fittings Water Heater Kit Radiation Shield Ratchet Cinch Tool Reducer, Copper	9 7 7 7 11 11 15 11 19 16 5 10 13 13 12 6 6 12
Plate Heat Exchanger Plate Mounting Bracket Plug-in Thermostat Pool Aquastat Power Supply Cord. Programmable 24-Volt Thermostat. Propane Shut-off with Level Indicator. Pulse Timer Kit Pump Flange Kits. Purging and Filling Tee Push-fit Fittings Push-fit Fittings Push-fit Fittings Water Heater Kit Radiation Shield Ratchet Cinch Tool Reducer, Copper Reducing Tee, Copper	9 7 7 7 11 11 15 11 19 16 5 10 13 13 12 12 12 12
Plate Heat Exchanger. Plate Mounting Bracket Plug-in Thermostat Pool Aquastat Power Supply Cord. Programmable 24-Volt Thermostat. Propane Shut-off with Level Indicator. Pulse Timer Kit Pump Flange Kits. Purging and Filling Tee Push-fit Fittings Push-fit Fittings Push-fit Fittings Water Heater Kit Radiation Shield Ratchet Cinch Tool Reducer, Copper Reducing Tee, Copper Reducing Tee, Copper Reinforced Wall Band.	9 7 7 11 11 15 11 19 16 16 10 13 13 12 12 12 12
Plate Heat Exchanger Plate Mounting Bracket Plug-in Thermostat Pool Aquastat Power Supply Cord Propane Shut-off with Level Indicator. Pulse Timer Kit Pump Flange Kits Purging and Filling Tee Push-fit Fittings Push-fit Fittings Water Heater Kit Radiation Shield Ratchet Cinch Tool Reducer, Copper Reducing Tee, Copper Reducing Tee, Copper Reinforced Wall Band Round Pipe Caps	9 7 7 11 11 15 11 19 16 16 10 13 13 12 19 19 19 19 19 19 19 19 19 19 19 19 19
Plate Heat Exchanger Plate Mounting Bracket Plug-in Thermostat Pool Aquastat Power Supply Cord. Programmable 24-Volt Thermostat. Propane Shut-off with Level Indicator. Pulse Timer Kit Pump Flange Kits. Purging and Filling Tee Push-fit Fittings Push-fit Fittings Push-fit Fittings Water Heater Kit Radiation Shield Ratchet Cinch Tool Reducer, Copper Reducing Tee, Copper Reinforced Wall Band. Round Pipe Caps. Single-stage, Non-programmable 24-Volt Thermostat.	9 7 7 7 11 11 15 11 19 16 5 10 13 13 12 10 6 12 12 11 11
Plate Heat Exchanger Plate Mounting Bracket Plug-in Thermostat Pool Aquastat Power Supply Cord. Programmable 24-Volt Thermostat. Propane Shut-off with Level Indicator. Pulse Timer Kit Pump Flange Kits. Purging and Filling Tee Push-fit Fittings Push-fit Fittings Push-fit Fittings Water Heater Kit Radiation Shield Ratchet Cinch Tool Reducer, Copper Reducing Tee, Copper Reducing Tee, Copper Reinforced Wall Band Round Pipe Caps Single-stage, Non-programmable 24-Volt Thermostat Sludge Conditioner	9 7 7 7 11 11 15 11 19 16 5 10 13 13 12 19 11 11 11 11 11 11 11 11 11 11 11 11
Plate Heat Exchanger Plate Mounting Bracket Plug-in Thermostat Pool Aquastat Power Supply Cord. Programmable 24-Volt Thermostat. Propane Shut-off with Level Indicator. Pulse Timer Kit Pump Flange Kits. Purging and Filling Tee Push-fit Fittings Push-fit Fittings Push-fit Fittings Water Heater Kit. Radiation Shield. Ratchet Cinch Tool Reducer, Copper Reducing Tee, Copper Reducing Tee, Copper Reinforced Wall Band. Round Pipe Caps Single-stage, Non-programmable 24-Volt Thermostat. Sludge Conditioner Solder & Soldering Flux Solenoid	9 7 7 7 11 11 11 15 11 19 16 15 10 13 13 13 16 16 16 16 16 16 16 16 16 16 16 16 16
Plate Heat Exchanger Plate Mounting Bracket Plug-in Thermostat Pool Aquastat Power Supply Cord. Programmable 24-Volt Thermostat. Propane Shut-off with Level Indicator. Pulse Timer Kit Pump Flange Kits. Purging and Filling Tee Push-fit Fittings Push-fit Fittings Push-fit Fittings Water Heater Kit Radiation Shield Ratchet Cinch Tool Reducer, Copper Reducing Tee, Copper Reducing Tee, Copper Reinforced Wall Band Round Pipe Caps Single-stage, Non-programmable 24-Volt Thermostat Sludge Conditioner Solder & Soldering Flux Solenoid Space Heater (100k Btu)	9 7 7 11 11 15 11 19 16 5 10 13 13 10 10 10 11 11 14 19 15 15 16 16 16 16 17 17 18 19 19 19 19 19 19 19 19 19 19 19 19 19
Plate Heat Exchanger Plate Mounting Bracket Plug-in Thermostat Pool Aquastat Power Supply Cord. Programmable 24-Volt Thermostat. Propane Shut-off with Level Indicator. Pulse Timer Kit Pump Flange Kits. Purging and Filling Tee Push-fit Fittings Push-fit Fittings Push-fit Fittings Water Heater Kit Radiation Shield Ratchet Cinch Tool Reducer, Copper Reducing Tee, Copper Reducing Tee, Copper Reinforced Wall Band Round Pipe Caps Single-stage, Non-programmable 24-Volt Thermostat Sludge Conditioner Solder & Soldering Flux Solenoid Space Heater (100k Btu)	9 7 7 11 11 15 11 19 16 5 10 13 13 10 10 10 11 11 14 19 15 15 16 16 16 16 17 17 18 19 19 19 19 19 19 19 19 19 19 19 19 19
Plate Heat Exchanger Plate Mounting Bracket Plug-in Thermostat Pool Aquastat Power Supply Cord Programmable 24-Volt Thermostat Propane Shut-off with Level Indicator. Pulse Timer Kit Pump Flange Kits Purging and Filling Tee Push-fit Fittings Push-fit Fittings Push-fit Fittings Water Heater Kit Radiation Shield Ratchet Cinch Tool Reducer, Copper Reducing Tee, Copper Reducing Tee, Copper Reducing Tee, Copper Single-stage, Non-programmable 24-Volt Thermostat Sludge Conditioner Solder & Soldering Flux Solenoid Space Heater (100k Btu) Space Heater (140k Btu) Space Heater Cabinet (50k Btu)	9 7 7 11 11 15 11 19 16 5 10 13 13 10 6 12 12 11 14 19 15 3 3 3 3 3 3 3 3 3 3 3 3 3 3 3 3 3 3
Plate Heat Exchanger Plate Mounting Bracket Plug-in Thermostat Pool Aquastat Power Supply Cord. Programmable 24-Volt Thermostat. Propane Shut-off with Level Indicator. Pulse Timer Kit Pump Flange Kits. Purging and Filling Tee Push-fit Fittings Push-fit Fittings Push-fit Fittings Water Heater Kit Radiation Shield Ratchet Cinch Tool Reducer, Copper Reducing Tee, Copper Reducing Tee, Copper Reinforced Wall Band Round Pipe Caps Single-stage, Non-programmable 24-Volt Thermostat Sludge Conditioner Solder & Soldering Flux Solenoid Space Heater (100k Btu) Space Heater Cabinet (50k Btu) Space Heater Cabinet (50k Btu) Space Heater Cabinet (50k Btu) Spack Arrestor.	9 7 7 11 11 5 11 19 16 5 10 13 3 20 6 2 2 1 1 1 4 9 15 3 3 3 3 7
Plate Heat Exchanger Plate Mounting Bracket Plug-in Thermostat Pool Aquastat Power Supply Cord. Programmable 24-Volt Thermostat. Propane Shut-off with Level Indicator. Pulse Timer Kit Pump Flange Kits. Purging and Filling Tee Push-fit Fittings Push-fit Fittings Push-fit Fittings Water Heater Kit Radiation Shield Ratchet Cinch Tool Reducer, Copper Reducing Tee, Copper Reducing Tee, Copper Reinforced Wall Band Round Pipe Caps Single-stage, Non-programmable 24-Volt Thermostat Sludge Conditioner Solder & Soldering Flux Solenoid Space Heater (100 Btu) Space Heater (140 Btu) Space Heater Cabinet (50 Btu) Spark Arrestor Suspended Space Heater (100 Btu)	977711151196500333061221911495333772
Plate Heat Exchanger Plate Mounting Bracket Plug-in Thermostat Pool Aquastat Power Supply Cord. Programmable 24-Volt Thermostat. Propane Shut-off with Level Indicator. Pulse Timer Kit Pump Flange Kits. Purging and Filling Tee Push-fit Fittings. Push-fit Fittings Water Heater Kit Radiation Shield Ratchet Cinch Tool Reducer, Copper Reducing Tee, Copper Reducing Tee, Copper Reducing Tee, Copper Reducing Tee, Copper Rodund Pipe Caps Single-stage, Non-programmable 24-Volt Thermostat Sludge Conditioner Solder & Soldering Flux Solenoid Space Heater (100k Btu) Space Heater Cabinet (50k Btu) Space Heater Cabinet (50k Btu) Spare Heater Cabinet (220k Btu) Suspended Space Heater (100k Btu) Suspended Space Heater (220k Btu)	9777111511965003320612219114953337222
Plate Heat Exchanger Plate Mounting Bracket Plug-in Thermostat Pool Aquastat Power Supply Cord. Programmable 24-Volt Thermostat. Propane Shut-off with Level Indicator. Pulse Timer Kit Pump Flange Kits. Purging and Filling Tee Push-fit Fittings. Push-fit Fittings Water Heater Kit Radiation Shield Ratchet Cinch Tool Reducer, Copper Reducing Tee, Copper Reducing Tee, Copper Reducing Tee, Copper Reducing Tee, Copper Rodund Pipe Caps Single-stage, Non-programmable 24-Volt Thermostat Sludge Conditioner Solder & Soldering Flux Solenoid Space Heater (100k Btu) Space Heater Cabinet (50k Btu) Space Heater Cabinet (50k Btu) Spare Heater Cabinet (220k Btu) Suspended Space Heater (100k Btu) Suspended Space Heater (220k Btu)	9777111511965003320612219114953337222
Plate Heat Exchanger Plate Mounting Bracket Plug-in Thermostat Pool Aquastat Power Supply Cord. Programmable 24-Volt Thermostat. Propane Shut-off with Level Indicator. Pulse Timer Kit Pump Flange Kits. Purging and Filling Tee Push-fit Fittings Push-fit Fittings Push-fit Fittings Water Heater Kit. Radiation Shield. Ratchet Cinch Tool Reducer, Copper Reducing Tee, Copper Reducing Tee, Copper Reinforced Wall Band. Round Pipe Caps Single-stage, Non-programmable 24-Volt Thermostat. Sludge Conditioner. Solder & Soldering Flux Solenoid. Space Heater (100k Btu) Space Heater Cabinet (50k Btu). Spark Arrestor. Suspended Space Heater (220k Btu). Sweat Ball Valve. Taco Pump Replacement Cartridges	9777111511965013320622219114953333722225
Plate Heat Exchanger Plate Mounting Bracket Plug-in Thermostat Pool Aquastat Power Supply Cord. Programmable 24-Volt Thermostat. Propane Shut-off with Level Indicator. Pulse Timer Kit Pump Flange Kits. Purging and Filling Tee Push-fit Fittings Push-fit Fittings Push-fit Fittings Water Heater Kit Radiation Shield Ratchet Cinch Tool Reducer, Copper Reducing Tee, Copper Reducing Tee, Copper Reinforced Wall Band Round Pipe Caps Single-stage, Non-programmable 24-Volt Thermostat Sludge Conditioner Solder & Soldering Flux Solenoid Space Heater (100k Btu) Space Heater (140k Btu) Space Heater (220k Btu) Spark Arrestor Suspended Space Heater (100k Btu) Suspended Space Heater (220k Btu) Sweat Ball Valve Taco Pump Replacement Cartridges Taco Pump Replacement Cartridges Taco Pump Replacement Cartridges	9777111511965003300622191149533317222255
Plate Heat Exchanger Plate Mounting Bracket Plug-in Thermostat Pool Aquastat Power Supply Cord Programmable 24-Volt Thermostat Propane Shut-off with Level Indicator. Pulse Timer Kit Pump Flange Kits Purging and Filling Tee Push-fit Fittings Push-fit Fittings Push-fit Fittings Water Heater Kit Radiation Shield Ratchet Cinch Tool Reducer, Copper Reducing Tee, Copper Reducing Tee, Copper Reducing Tee, Copper Reducing Tee, Sopper Reducing Tee, Sopper Single-stage, Non-programmable 24-Volt Thermostat Sludge Conditioner Solder & Soldering Flux Solenoid Space Heater (100k Btu) Space Heater (410k Btu) Space Heater (410k Btu) Space Heater Cabinet (50k Btu) Space Heater Cabinet (50k Btu) Suspended Space Heater (220k Btu) Sweat Ball Valve. Taco Pump Replacement Cartridges Taco Pumps - 006 Series Taco Pumps - 007 Series	977711151196500330062219114953331722225555
Plate Heat Exchanger Plate Mounting Bracket Plug-in Thermostat Pool Aquastat Power Supply Cord. Programmable 24-Volt Thermostat. Propane Shut-off with Level Indicator. Pulse Timer Kit Pump Flange Kits Purging and Filling Tee Push-fit Fittings Push-fit Fittings Push-fit Fittings Push-fit Fittings Water Heater Kit. Radiation Shield. Ratchet Cinch Tool Reducer, Copper Reducing Tee, Coppe	977711151196503330622219114953337222255555
Plate Heat Exchanger Plate Mounting Bracket Plug-in Thermostat Pool Aquastat Power Supply Cord. Programmable 24-Volt Thermostat. Propane Shut-off with Level Indicator. Pulse Timer Kit Pump Flange Kits. Purging and Filling Tee Push-fit Fittings Push-fit Fittings Push-fit Fittings Water Heater Kit. Radiation Shield. Ratchet Cinch Tool Reducer, Copper Reducing Tee, Copper Reducing Tee, Copper Reinforced Wall Band. Round Pipe Caps. Single-stage, Non-programmable 24-Volt Thermostat. Sludge Conditioner. Solder & Soldering Flux Solenoid Space Heater (100k Btu) Space Heater (100k Btu) Space Heater Cabinet (50k Btu). Spark Arrestor. Suspended Space Heater (100k Btu). Suspended Space Heater (220k Btu). Sweat Ball Valve. Taco Pump Replacement Cartridges Taco Pumps - 006 Series Taco Pumps - 007 Series Taco Pumps - 009 & 014 Series Tee	97771115119165013130161212119114915333722212555553
Plate Heat Exchanger Plate Mounting Bracket Plug-in Thermostat Pool Aquastat Power Supply Cord Programmable 24-Volt Thermostat. Propane Shut-off with Level Indicator. Pulse Timer Kit Pump Flange Kits. Purging and Filling Tee Push-fit Fittings Push-fit Fittings Push-fit Fittings Water Heater Kit Radiation Shield Ratchet Cinch Tool Reducer, Copper Reducing Tee, Copper Reducing Tee, Copper Reinforced Wall Band Round Pipe Caps Single-stage, Non-programmable 24-Volt Thermostat Sludge Conditioner Solder & Soldering Flux Solenoid Space Heater (100k Btu) Space Heater (140k Btu) Space Heater (220k Btu) Spark Arrestor Suspended Space Heater (220k Btu) Sweat Ball Valve. Taco Pumps - 006 Series Taco Pumps - 007 Series Taco Pumps - 009 & 014 Series Tee Tee, 3/4" NPT	97771115119650333062221911495333372222555539
Plate Heat Exchanger Plate Mounting Bracket Plug-in Thermostat Pool Aquastat Power Supply Cord. Programmable 24-Volt Thermostat. Propane Shut-off with Level Indicator. Pulse Timer Kit Pump Flange Kits. Purging and Filling Tee Push-fit Fittings Push-fit Fittings Push-fit Fittings Water Heater Kit. Radiation Shield. Ratchet Cinch Tool Reducer, Copper Reducing Tee, Copper Reducing Tee, Copper Reinforced Wall Band. Round Pipe Caps. Single-stage, Non-programmable 24-Volt Thermostat. Sludge Conditioner. Solder & Soldering Flux Solenoid Space Heater (100k Btu) Space Heater (100k Btu) Space Heater Cabinet (50k Btu). Spark Arrestor. Suspended Space Heater (100k Btu). Suspended Space Heater (220k Btu). Sweat Ball Valve. Taco Pump Replacement Cartridges Taco Pumps - 006 Series Taco Pumps - 007 Series Taco Pumps - 009 & 014 Series Tee	97711151196503330622219114953333722225555392
Plate Heat Exchanger Plate Mounting Bracket Plug-in Thermostat Pool Aquastat Power Supply Cord. Programmable 24-Volt Thermostat. Propane Shut-off with Level Indicator. Pulse Timer Kit Pump Flange Kits. Purging and Filling Tee Push-fit Fittings Push-fit Fittings Push-fit Fittings Water Heater Kit. Radiation Shield. Ratchet Cinch Tool Reducer, Copper Reducing Tee, Copper Reducing Tee, Copper Reinforced Wall Band. Round Pipe Caps. Single-stage, Non-programmable 24-Volt Thermostat. Sludge Conditioner. Solder & Soldering Flux Solenoid. Space Heater (100k Btu) Space Heater (100k Btu) Space Heater Cabinet (50k Btu). Space Heater Cabinet (50k Btu). Spark Arrestor. Suspended Space Heater (220k Btu). Sweat Ball Valve. Taco Pump Replacement Cartridges Taco Pumps - 006 Series Taco Pumps - 007 Series Taco Pumps - 007 Series Taco Pumps - 009 & 014 Series Tee Temperature Gauge Fitting. Temperature Gauge Fitting.	97771115119650033006122191149533337222125555391234
Plate Heat Exchanger Plate Mounting Bracket Plug-in Thermostat Pool Aquastat Power Supply Cord. Programmable 24-Volt Thermostat. Propane Shut-off with Level Indicator. Pulse Timer Kit Pump Flange Kits. Purging and Filling Tee Push-fit Fittings Push-fit Fittings Push-fit Fittings Water Heater Kit. Radiation Shield. Ratchet Cinch Tool Reducer, Copper Reducing Tee, Copper Reducing Tee, Copper Reinforced Wall Band. Round Pipe Caps. Single-stage, Non-programmable 24-Volt Thermostat. Sludge Conditioner. Solder & Soldering Flux Solenoid. Space Heater (100k Btu) Space Heater (100k Btu) Space Heater Cabinet (50k Btu). Space Heater Cabinet (50k Btu). Spark Arrestor. Suspended Space Heater (220k Btu). Sweat Ball Valve. Taco Pump Replacement Cartridges Taco Pumps - 006 Series Taco Pumps - 007 Series Taco Pumps - 007 Series Taco Pumps - 009 & 014 Series Tee Temperature Gauge Fitting. Temperature Gauge Fitting.	97771115119650033006122191149533337222125555391234
Plate Heat Exchanger Plate Mounting Bracket Plug-in Thermostat Pool Aquastat Power Supply Cord Programmable 24-Volt Thermostat Propane Shut-off with Level Indicator. Pulse Timer Kit Pump Flange Kits Purging and Filling Tee Push-fit Fittings Push-fit Fittings Push-fit Fittings Push-fit Fittings Water Heater Kit Radiation Shield Ratchet Cinch Tool Reducer, Copper Reducing Tee, Solder Mall Band Round Pipe Caps Single-stage, Non-programmable 24-Volt Thermostat Sludge Conditioner Solder & Soldering Flux Solenoid Space Heater (100k Btu) Space Heater (140k Btu) Space Heater (40k Btu) Space Heater Cabinet (50k Btu). Spark Arrestor Suspended Space Heater (100k Btu). Suspended Space Heater (220k Btu). Sweat Ball Valve. Taco Pump Replacement Cartridges Taco Pumps - 006 Series Taco Pumps - 007 Series Taco Pumps - 009 & 014 Series Tee Tee, 3/4" NPT Tee, Copper Temperature Gauge Fitting Tempering Valve ThermoPEX	977111511965033306222191149533372222555539234117
Plate Heat Exchanger Plate Mounting Bracket Plug-in Thermostat Pool Aquastat Power Supply Cord Programmable 24-Volt Thermostat Propane Shut-off with Level Indicator. Pulse Timer Kit Pump Flange Kits Purging and Filling Tee Push-fit Fittings Push-fit Fittings Push-fit Fittings Push-fit Fittings Water Heater Kit Radiation Shield Ratchet Cinch Tool Reducer, Copper Reducing Tee, Solder Mall Band Round Pipe Caps Single-stage, Non-programmable 24-Volt Thermostat Sludge Conditioner Solder & Soldering Flux Solenoid Space Heater (100k Btu) Space Heater (140k Btu) Space Heater (40k Btu) Space Heater Cabinet (50k Btu). Spark Arrestor Suspended Space Heater (100k Btu). Suspended Space Heater (220k Btu). Sweat Ball Valve. Taco Pump Replacement Cartridges Taco Pumps - 006 Series Taco Pumps - 007 Series Taco Pumps - 009 & 014 Series Tee Tee, 3/4" NPT Tee, Copper Temperature Gauge Fitting Tempering Valve ThermoPEX	977111511965033306222191149533372222555539234117
Plate Heat Exchanger Plate Mounting Bracket Plug-in Thermostat Pool Aquastat Power Supply Cord. Programmable 24-Volt Thermostat. Propane Shut-off with Level Indicator. Pulse Timer Kit Pump Flange Kits. Purging and Filling Tee Push-fit Fittings Push-fit Fittings Push-fit Fittings Water Heater Kit. Radiation Shield. Ratchet Cinch Tool Reducer, Copper Reducing Tee, Copper Reducing Tee, Copper Reinforced Wall Band. Round Pipe Caps. Single-stage, Non-programmable 24-Volt Thermostat. Sludge Conditioner. Solder & Soldering Flux Solenoid Space Heater (100k Btu) Space Heater (100k Btu) Space Heater (20k Btu) Space Heater (20k Btu). Spark Arrestor. Suspended Space Heater (220k Btu). Sweat Ball Valve. Taco Pump Replacement Cartridges Taco Pumps - 006 Series Taco Pumps - 007 Series Taco Pumps - 007 Series Taco Pumps - 007 Series Taco Pumps - 008 Solies Tee Tee, 3/4" NPT Tee, Copper Temperature Gauge Fitting. Temperature Gauge Fitting. Temperature Gauges Tempering Valve. ThermoPEX Coupling Kit ThermoPEX Termination Cap.	9771115119650332062221911495333722225555539234117777
Plate Heat Exchanger Plate Mounting Bracket Plug-in Thermostat Pool Aquastat Power Supply Cord Programmable 24-Volt Thermostat Propane Shut-off with Level Indicator. Pulse Timer Kit Pump Flange Kits Purging and Filling Tee Push-fit Fittings Push-fit Fittings Push-fit Fittings Push-fit Fittings Water Heater Kit Radiation Shield Ratchet Cinch Tool Reducer, Copper Reducing Tee, Solder Mall Band Round Pipe Caps Single-stage, Non-programmable 24-Volt Thermostat Sludge Conditioner Solder & Soldering Flux Solenoid Space Heater (100k Btu) Space Heater (140k Btu) Space Heater (40k Btu) Space Heater Cabinet (50k Btu). Spark Arrestor Suspended Space Heater (100k Btu). Suspended Space Heater (220k Btu). Sweat Ball Valve. Taco Pump Replacement Cartridges Taco Pumps - 006 Series Taco Pumps - 007 Series Taco Pumps - 009 & 014 Series Tee Tee, 3/4" NPT Tee, Copper Temperature Gauge Fitting Tempering Valve ThermoPEX	9771115119650332062221911495333722225555539234117777

Thermostatic Radiator Valves. Tile Tape Universal Heat Exchanger Mounting Kit. Universal Offset/Wall Support. Universal Pump Wall Mount Kit Universal Roof Brace Universal Roof Support Vent Cap - Classic Models Vent Elbow, Copper Wall Band Extension. Wall Mount Fan Convector Wall Mount Fan Convector (7k Btu) Wall Radiation Shield Water Softener Cartridge Water Test Kit Water-to-Water Heat Exchanger, Double Wall Water-to-Water Heat Exchanger, Shell & Tube Wonder Bar Y-Strainer	.1.2.2.1.1.1	48000445044866

WATER-TO-AIR HEAT EXCHANGER PRODUCTS

Heat Exchanger Coil (50k Btu)




Water-to-air heat exchanger coil with 90° 3/4" female pipe thread (FPT) outlets. Dimensions: 12-3/4" x 14" x 4-1/8".

p/n Description

Heat Exchanger Coil, 50k Btu

Heat Exchanger Coil (80k Btu)




Water-to-air heat exchanger coil with straight 3/4" FPT outlets. Used in forced-air furnaces with plenum size of approximately 13" x 18". Dimensions: 12-3/4" x 18" x 4-1/8".

p/n Description

109 Heat Exchanger Coil, 80k Btu

Heat Exchanger Coil (95k Btu)




Water-to-air heat exchanger coils with straight 3/4" FPT outlets. Used in forced-air furnaces with plenum size of approximately 15" x 18". Dimensions: 15" x 20" x 4-1/8".

p/n Description

102 Heat Exchanger Coil, 95k Btu

Heat Exchanger Coil (100k Btu)




Water-to-air heat exchanger coil with straight 3/4" FPT outlets. Used in forced-air furnaces with plenum size of approximately 17" x 18". Dimensions: 16-1/2" x 19" x 4-1/8".

p/n Description

06 Heat Exchanger Coil, 100k Btu

Heat Exchanger Coil (125k Btu)




Water-to-air heat exchanger coil with straight (p/n 107) or 90-degree (p/n 704) 3/4" FPT outlets. Used in forced-air furnaces with plenum size from approximately 18" x 18" to 18" x 20". Dimensions: 17-3/4" x 20" x 4-1/8".

n Description

107 Heat Exchanger Coil, 125k Btu, straight outlets 704 Heat Exchanger Coil, 125k Btu, 90° outlets

Heat Exchanger Coil (140k Btu)




Water-to-air heat exchanger coil with straight 3/4" FPT outlets. Used in forced-air furnaces with plenum size of approximately 20" x 20". Dimensions: 19" x 21" x 4-1/8".

/n Description

108 Heat Exchanger Coil, 140k Btu

Heat Exchanger Coil (185k Btu)




Water-to-air heat exchanger coil with straight 3/4" FPT outlets. Used in forced-air furnaces with plenum size of approximately 23" x 23". Dimensions: 22-3/4" x 24" x 4-1/8".

/n Description

110 Heat Exchanger Coil, 185k Btu

Heat Exchanger Coil (220k Btu)




Water-to-air heat exchanger coil with straight 3/4" FPT outlets. Used in forced-air furnaces with plenum size of approximately 24" x 24". Dimensions: 24" x 26" x 4-1/8".

p/n Description

111 Heat Exchanger Coil, 220k Btu

Suspended Space Heater (100k Btu)



Order the following components for a complete Suspended Space Heater (100k Btu). Some assembly required. Assembled size approximately 19" x 16-1/2" x 16". Allow at least 6" on side for fittings.


p/n Description

322 Fan

323 Transition

106 Heat Exchanger Coil, 100k Btu

Suspended Space Heater (220k Btu)



Order the following components for a complete Suspended Space Heater (220k Btu). Some assembly required. Assembled size approximately 26" x 24" 20". Allow at least 6" on side for fittings.

p/n Description

111 Heat Exchanger Coil, 220k Btu


849 Transition 848 Motor Fran

Motor Frame

851 Fan Blades 1280 Fan Motor

WATER-TO-AIR HEAT EXCHANGER PRODUCTS

Blower & Motor



Blower & Motor assembly available in different

p/n	Description

203

Blower & Motor, 1/15-hp Blower & Motor, 1/4-hp, 3-speed fan Blower & Motor, 1-hp 154

Louvers




Bolt on to the face of the heat exchanger to direct heat downward.

Description

Louvers, fit Heat Exchanger Coil (p/n 106) 354 Louvers, fit Heat Exchanger Coil (p/n 108)

Louvers, fit Heat Exchanger Coil (p/n 111)

Space Heater Cabinet (50k Btu)



Cabinet for housing 1/15-hp Blower & Motor (p/n 203) and 50k Btu Heat Exchanger Coil (p/n 287). Each sold separately. Some assembly required. Dimensions: 16" x 19-3/4" x 13-1/4".

Description Space Heater Cabinet

Space Heater (100k Btu)




Order the following components for a Space Heater (100k Btu). Some assembly required. Assembled size approximately 19" x 21" x 33".

p/n Description

Transition

Blower & Motor, 1/4-hp 3-speed fan Heat Exchanger Coil, 100k Btu 154 106

Space Heater (140k Btu)



Order the following components for a Space Heater (140k Btu). Some assembly required. Assembled size approximately 19" x 21" x 33".

Description

415

Transition Blower & Motor, 1/4-hp 3-speed fan 154

Heat Exchanger Coil, 140k Btu

Air Handler Cabinet



Two sizes allow multiple applications from 100k Btu to 220k Btu; cabinets are standard with front water access (refer to the chart below for specific applications). NOTE: Blower & Motor and Heat Exchanger Coil are sold separately. Air Handler Cabinet door is capable of holding a filter (not included). Some assembly will be required. If utilizing an existing 24-volt thermostat to control blower, a Fan Center Relay (p/n 515) must be used.

p/n	Dimensions (in.)	Heat Exch. Coil Range		Water Access
301	36 x 20 x 23	100k-140k Btu	1/4-hp	Front
	Filter (not inclu			
303	39 x 25 x 28	185k-220k Btu	1-hp	Front
	Filter (not inclu	ided): 20 x 20		

Description


Air Handler Cabinet, 100k-140k Btu, front access

Kit for 301 - back water access

Air Handler Cabinet, 185k-220k Btu, front access

3825 Kit for 303 - back water access

Fan Convector (26k Btu)




Central Boiler fan-forced convector. Quiet operation, integral filters and thermostat connections. 3/4" FPT fittings and on-offthermostat switch. Output up to 26,000 Btu/hr. Color - taupe. Line Voltage Thermostat (p/n 1267) is optional.

Fan Convector, 26k Btu

Line Voltage Thermostat

Wall Mount Fan Convector (7k Btu)




fan-forced Central Boiler recessed wall, convector. Quiet operation, integral filters and thermostat connections. Can use Female Adapter (p/n 6679) or Push-fit Fitting (p/n 606) for connection. 1/2" fittings and on-off-thermostat switch. Output up to 7,000 Btu/hr. Line Voltage Thermostat (p/n 1267) is optional.

Description

Fan Convector, Wall Mount, 7k Btu

Line Voltage Thermostat

Corner Fan Convector (7k Btu)



Central Boiler fan-forced convector. Quiet operation, integral filters and thermostat connections. Can use Female Adapter (p/n 6679) or Push-fit Fitting (p/n 606) for connection. 1/2" fittings and on-off-thermostat switch. Output up to 7,000 Btu/hr. Line Voltage Thermostat (p/n 1267) is optional.


Description

Fan Convector, Corner, 7k Btu

1267 Line Voltage Thermostat

WATER-TO-AIR HEAT EXCHANGER PRODUCTS


Wall Mount Fan Convector



Myson Lo-Line $^{\rm TM}$ RC 6-4 wall mount, fan-forced convector with thermostat, output of 4,213-6,531 Btu/hr. Dimensions: 20-3/16" x 18-1/2" x 5-1/2". Weight: 16 lbs. Fan speed (cfm): boost - 72, medium - 51, normal - 58.

p/n Description 6776 Myson Lo-Line RC 6-4 Fan Convector

Wall Mount Fan Convector



Myson Slim-Line[™] RC wall mount, fan-forced convector with remote control, output of 11,882-15,293 Btu/hr. Dimensions: 15-9/16" x 31-7/8" x 6-11/16". Weight: 37 lbs. Fan speed (cfm): boost - 136, medium - 127, normal - 96.

p/n Description 6778 Myson Slim-Line RC Fan Convector


Wall Mount Fan Convector



Myson Hi-Line $^{\top M}$ HL 7-4 wall mount, fan-forced convector, output of 4,377-7,851 Btu/hr. Dimensions: 20-5/8" x 14-1/4" x 5". Weight: 22 lbs. Fan speed (cfm): boost - 78, medium - 62, normal - 48.

p/n Description 6777 Myson Hi-Line HL 7-4 Fan Convector


Wall Mount Fan Convector



Myson CSU™ 15M wall mount, fan-forced convector. Output of 7,315-10,330 Btu/hr. Dimensions: 28-7/8" x 13-1/4" x 4-3/4". Weight: 22 lbs. Fan speed (cfm): boost - 91, normal - 66.

p/n Description6779 Myson CSU 15M Fan Convector


Floor Fan Convector



Myson Whispa™ III recessed floor, fan-forced convector, output of 4,078-5,443 Btu/hr. Dimensions: 14-1/4" x 8-1/4" x 9-7/16". Weight: 12 lbs. Fan speed (cfm): boost - 81, normal - 62. Cover is 9-3/4" x 15-7/8".

p/n Description6839 Myson Whispa III Fan Convector


Kickspace Fan Convector



Myson Whispa™ III Kickspace 9000 fan-forced convector, output of 7,634-9,949 Btu/hr. Dimensions: 17-3/4" x 16" x 3-1/2". Weight: 12 lbs. Fan speed (cfm): boost - 124, normal - 82. Cover grill is 4" x 22-1/2".

p/n Description6773 Myson Whispa II Kickspace 9000 Fan Convector

Kickspace Fan Convector



Myson Whispa™ III Kickspace 5000 fan-forced convector, output of 4,078-5,443 Btu/hr. Dimensions: 14-1/4" x 12-1/8" x 3-1/2". Weight: 9 lbs. Fan speed (cfm): boost - 53, normal - 41. Cover grill is 4" x 18-1/2".

p/n Description
 6780 Myson Whispa II Kickspace 5000 Fan Convector

PUMPS AND PUMP ACCESSORIES

Taco Pumps - 006 Series




Taco 006 Bronze Circulation Pump for domestic water systems. No flange required, 3/4" sweat connection. Power Supply Cord (p/n 556) sold separately.

				Head	Volume
size 006	hp 1/40	Amp 0.52	Watt 59.8	(ft) 9	(gal/min) 10

p/n Description Taco 006 Pump

Taco Pumps - 007 Series



Taco 007 Circulation Pump requires flange kit (not included). Includes O-rings. Power Supply Cord (p/n 556) sold separately.

size	hp	Amp	Watt	Head (ft)	Volume (gal/min)
007	1/25	0.70	80.50	11	20
007 Priority	1/25	0.70	81.65	11	20

Description Taco 007 Pump Taco 007 Priority Pump

Taco Pumps - 009 & 014 Series



Taco 009 and Taco 014 Circulation Pumps both require flange kit (not included). Includes O-rings. Power Supply Cord (p/n 556) sold separately.

size	hp	Amp	Watt	Head (ft)	Volume (gal/min)
009	1/8	1.40	161	34	8
014	1/8	1.55	178	22	32

Description Taco 009 Pump Taco 014 Pump

Power Supply Cord



May be used to wire pumps when installed on furnaces. Includes strain relief.

Description Power Supply Cord, 32"

0-Ring Set

Set of two replacement O-rings for pump flange.

Description O-Ring Set

Taco Pump Replacement Cartridges



For 006 and 007 **Pumps**



For 009 & 011 Pumps


Replacement cartridges for Taco 006, 007, 009, 011 and 014 series pumps. Each includes a 3-year warranty.

Application

Replacement Cartridge, 006 Series Pumps Replacement Cartridge, 007 Series Pumps

170 Replacement Cartridge, 009 Series Pumps Replacement Cartridge, 011 Series Pumps Replacement Cartridge, 014 Series Pumps 172 219 179


Isolation Flange Kit



Kit includes flanges, nuts and bolts. Full port, valved flange body.

p/n 224 Description "Free Floating" Flange Kit, 3/4" Isolation Flange Kit, 1-1/4"


Isolation Flange with Drain Valve, 3/4"



Includes flange, nuts and bolts.

Description Isolation Flange with Drain Valve, 3/4" NOTE: Price is for one flange only.


Pump Flange Kits



Each kit includes set of two female iron pipe (FIP) pump flanges. One set is used with each pump. Most installations use Pump Flange Kit, 3/4" (p/n 119).

Description Pump Flange Kit, 3/4" Pump Flange Kit, 1 1272 Pump Flange Kit, 1-1/4"

Universal Pump Wall Mount Kit



Brackets for supporting and securing pump and flanges to a wall. Figure shows one possible installation scenario. Pump, flanges and mounting hardware are not included.

p/n Description 1366 Universal Pump Wall Mount Kit

PEX PIPE, FITTINGS AND RELATED

PEX Pipe Cutter



Used to cut PEX pipe up to 1-1/4" in diameter.

p/n Description 195 PEX Pipe Cutter

Central PEX 1/2" Pipe



High-density, oxygen barrier, cross-link pipe. Rated for temperatures to 180°F at 100 psi. Available in rolls up to 1000 ft long. Excellent for radiant floor heating applications.

 p/n
 Description

 1320
 Central PEX 1/2" Pipe, 300'

 1321
 Central PEX 1/2" Pipe, 500'

 1322
 Central PEX 1/2" Pipe, 1000'

Central PEX 1" Pipe



High-density, cross-link pipe, rated fo temperatures to 180°F at 100 psi.

 p/n
 Description

 1311
 Central PEX 1" Pipe, 100'

 1312
 Central PEX 1" Pipe, 200'

 1313
 Central PEX 1" Pipe, 300'

 1314
 Central PEX 1" Pipe, 500'


Central PEX 1" Pipe Sections



Central PEX 1" Pipe in 10-ft sections.

p/n Description
1302 Central PEX 1" Pipe, 10' straight section, 5 per bag
1303 Central PEX 1" Pipe, 10' straight section, 20 per bag

PEX Brass Clamp Fittings



Brass adapter clamps for PEX pipe.

p/n Description
5642 Brass Clamp Fittings, 1"
5643 Brass Clamp Fittings, 1-1/4"

PEX Adapter



For adapting threaded pipe to Central PEX pipe.

p/n Description
1341 PEX Adapter, 1/2" PEX x 1/2" MIP fittings
1330 PEX Adapter, 1/2" PEX x 3/4" MIP fittings
1330 PEX Adapter, 1" PEX x 3/4" MIP fittings
1324 PEX Adapter, 1" PEX x 1" MIP fittings

PEX Adapter



For adapting copper pipe to Central PEX pipe.

p/n Description
1337 PEX Adapter, 1/2" PEX x 1/2" sweat fittings
1331 PEX Adapter, 1" PEX x 1" sweat fittings
1348 PEX Adapter, 1/2" PEX x 1/2" FIP fittings

Female Adapter



Adapts 1/2" copper pipe to 1/2" Central PEX pipe. Sweat end fits over copper pipe.

p/n Description 6679 Female Adapter, 1/2" barb x 1/2" sweat fittings

PEX Coupling



For coupling two Central PEX pipe ends.

p/n Description 1339 PEX Coupling, 1/2" 1333 PEX Coupling, 1"

PEX 90° Elbow



Brass 90° elbow for coupling two Central PEX pipe ends together.

p/n Description 1340 PEX 90° Elbow, 1/2" 1334 PEX 90° Elbow, 1"

PEX Tee



Brass tee for joining Central PEX pipe ends.

p/n Description 1338 PEX Tee, 1/2" 1332 PEX Tee, 1"

Central Boiler Clamp, 1"



Stainless steel 1" hose clamp.

p/n Description 5978 Central Boiler Clamp. 1"

PEX Crimp Rings / Crimp Tools



PEX Crimp Ring for PEX pipe. Crimp Tool (p/n 324) required for 1/2" crimp ring. Crimp Tool (p/n 145) required for 1" crimp ring.

p/n Description 1342 PEX Crimp Ring, 1/2" 1335 PEX Crimp Ring, 1" 324 Crimp Ring Tool, 1/2" 145 Crimp Ring Tool, 1"

Cinch Tool



Tool for cinching 1" and 1/2" PEX Stainless Steel Clamp Crimp Rings to PEX pipe. Not for use with any other application.

p/n Description 5925 Cinch Tool

Ratchet Cinch Tool



Compact, easy-to-use Ratchet Cinch Tool comes with handy carrying case and calibrating device. For use with 5927 and 5926 crimp rings.

p/n Description 4472 Ratchet Cinch Tool


PEX Stainless Steel Clamp Crimp Ring



For use with Central PEX pipe. Install with Cinch Tool (p/n 5925) or Ratchet Cinch Tool (p/n 4472).

p/n
5927
5926
PEX Stainless Steel Clamp Crimp Ring, 1/2"
5926
PEX Stainless Steel Clamp Crimp Ring, 1"

Clamp Crimp Ring Removal Tool



Used to remove PEX stainless steel clamp crimp rings (p/n 5927 and 5926).

p/n Description104 Clamp Crimp Ring Removal Tool

THERMOPEX, CENTRAL THERM, MANIFOLDS AND WATER-TO-WATER EXCHANGERS

PEX Hanger



Half-moon, nail-in PEX Hanger for securing PEX piping. Available in two sizes.

Description PEX Hanger, 1/2" PEX Hanger, 1"

ThermoPEX



ThermoPEX is flexible pre-insulated piping consisting of two waterproof oxygen barrier PEX lines (supply and return) protected by polyurethane closed cell foam insulation and a thick, durable, waterproof polyethylene outer jacket. It is the ideal insulated piping for use with outdoor wood furnaces. Available with 1" Central PEX in 100-ft or 800-ft rolls, or with 1-1/4" PEX in a 300-ft roll.

p/n Description ThermoPEX, 1", 100' Roll ThermoPEX, 1", 800' Roll 2491 2492 ThermoPEX, 1-1/4", 300' Roll

ThermoPEX Termination Cap



Fits snuggly over each end to protect and seal the insulation from water.

Description ThermoPEX Cap, 1" 2494 ThermoPEX Cap, 1-1/4"

ThermoPEX Coupling Kit





Twelve-inch rubber splice is used to join two ends of ThermoPEX together. Fittings and crimp rings for joining the PEX lines are sold separately.


Description 2447

ThermoPEX Coupling Kit, 1" 2495 ThermoPEX Coupling Kit, 1-1/4"

PEX Coupling, 1

Brass Coupling, 1-1/4" barb x 1-1/4" barb

Central Therm Insulation



Closed-cell, green polyethylene Central Therm Insulation for insulating water lines. Available in either 8-ft or 4-ft lengths.

Description

Central Therm Insulation, 8' Central Therm Insulation, 4'

Central Therm Sleeve



Central Therm Sleeve slips over Central Therm Insulation to keep insulation dry and increase heat transfer efficiency, especially in the spring when ground water is high. Available in lengths from 100 to 800 feet.

Description Central Therm Sleeve, 100' Central Therm Sleeve, 200' Central Therm Sleeve, 300' Central Therm Sleeve, 500' Central Therm Sleeve, 800'

Central Therm Sleeve Dispenser



Handy dispenser holds all roll lengths of Central Therm Sleeve.

Description Central Therm Sleeve Dispenser

Manifold w/Valves



For use with 1/2" PEX pipe in radiant floor installations, the Manifold w/Valves is available in a 2- or 3-loop configuration. Manifold fittings are 1" copper sweat; valve fittings are 1/2" barbed.

Description 1349 Manifold w/Valves, 2-Loop Manifold w/Valves, 3-Loop Copper Cap, 1"

Manifold w/o Valves



For use with 1/2" PEX pipe in radiant floor installations, the Manifold w/o Valves is available in a 2- or 3-loop configuration. Manifold fittings are 1" copper sweat; valve fittings are 1/2" barbed. Does not include valves or caps.

Description Manifold w/o Valves, 2-Loop Manifold w/o Valves, 3-Loop

Plate Heat Exchanger



The Plate Heat Exchanger is a compact, highperformance, water-to-water, continuous flow heat exchanger with MPT ports. Units are 316L stainless, copper-brazed. MPN units include mounting studs and are marine-grade stainless, nickel-brazed (for use with pools and hot tubs).

p/n	Typical Application
5734	Water heaters
5744	Boilers up to 100k Btu
5636	Boilers 100k-175k Btu
5637	Boilers 175k-250k Btu
5635	Large commercial

Description 5734 Plate Exchanger, 5 x 12-6, 3/4" Port Plate Exchanger, 5 x 12-30, 1" Port

Plate Exchanger, 5 x 12-50, 1-1/4" Port 5636 Plate Exchanger, 5 x 12-70, 1-1/4" Port

5635 Plate Exchanger, 10 x 20-50, 2" Port

MPN Units*

p/n	Approximate Btu	Typical Application
5738	80-120k	Hot tubs & pools up to 12,000 gallons
5842	150-200k	Pools up to approx. 30,000 gallons
128	250-320k	Pools up to approx. 50,000 gallons
129	280-360k	Pools up to approx. 60,000 gallons

Description

Plate Exchanger, MPN 5 x 12-10, 1" Port Plate Exchanger, MPN 5 x 12-24, 1-1/4" Port

Plate Exchanger, MPN 5 x 12-40, 1-1/4" Port Plate Exchanger, MPN 5 x 12-50, 1-1/4" Port

*MPN units are not recommended for use with salt chlorinated pools or hot tubs.

Plate Mounting Bracket



Used to mount most 5" x 12" Plate Heat Exchangers (30 or less) with mounting studs to a wall or similar surface.

Description Plate Mounting Bracket

WATER-TO-WATER EXCHANGERS

Heat Exchanger Mounting Kit



Used to mount most 5x12 Plate Heat Exchangers (40 or more) with mounting studs to a wall or similar surface. Includes two mounting brackets.

Description

Heat Exchanger Mounting Kit

Universal Heat Exchanger Mounting



Description

1097 Universal Heat Exchanger Mounting Kit


Flow Check Valve



Used in hydronic heating to prevent ghost flow when the components are above the manifold. Can be installed horizontally or vertically.

DescriptionFlow Check Valve, 1" threaded


Fittings Kit, Threaded



For domestic water heaters using Plate Heat Exchanger (p/n 5734).

p/n Description5640 Fittings Kit, threaded ports

Water-to-Water Heat Exchanger, Shell & Tube




water-to-water, continuous-flow exchanger used mainly for boiler applications. Side ports are 3/4" FIP; end ports are 1-1/2" FIP.

p/n 151 Description

Water-to-Water Heat Exchanger, Shell & Tube, 60"

Water-to-Water Heat Exchanger, Shell & Tube




water-to-water. continuous-flow exchanger for commercial water heater applications. Side ports are 3/4" FIP; end ports are 1-1/2" FIP.

Description

Water-to-Water Heat Exchanger, Shell & Tube, 27" . 148


Water-to-Water Heat Exchanger, Shell & Tube



water-to-water. continuous-flow heat exchanger used mainly for boiler applications. Side ports are 1" FIP; end ports are 1-1/2" FIP.

Heat Exchanger, Water-to-Water, Shell & Tube, 48"

Water-to-Water Heat Exchanger, **Double Wall**




Water-to-Water, Double Wall Heat Exchanger is a water-to-water, domestic water heat exchanger with 3/4" copper sweat ports. Install on existing water heater for thermal circulating heat transfer.

Description

Heat Exchanger, Water-to-Water, Double Wall, 42"

Water-to-Water Heat Exchanger & **Fittings Kit**



Install on existing domestic water heater for thermal circulating heat transfer. Side ports and end ports are 3/4" FIP. Fittings Kit is sold separately.

Description

Water-to-Water Heat Exchanger, 40"

2053 Fittings Kit

Automatic Vent Valve




Vents air automatically. For use in pressurized systems only. Fitting is 1/8" NPT.

Description **p/n** 286

Automatic Vent Valve

Panel Radiators



Type 21G Double Panel Single Convector and Type 22G Double Convector panel radiators in various sizes and Btu output. Valves (p/n 604, 605 are sold separately).

p/n	Baseboard Equivalent	Output (Btu/hr)	Fan Convector Equivalent
600	6 feet	3,100	N/A
601	10 feet	5,000	6777, 6774, 6839
602	14 feet	7,200	6776, 6780
603	18 feet	10,000	6779, 6773

- · No electricity required, no thermostats, no extra pumps
- · Easy installation includes mounting bracket and thread sealer

p/n Description 600 Panel Radiator, 32" x 16" 601 Panel Radiator, 35-1/2" x 24' Panel Radiator, 51-1/2" x 24' 602

Panel Radiator, 55-1/4" x 24"

Thermostatic Radiator Valves

LKD



Each valve body is threaded for nominal iron pipe threads and also comes with a compression nut and ferrule.

Description

TRV II Valve Body and Head, 1/2" Vertical

LKD Valve Body with No Cap, 1/2" Preset Flow Rate

SOLDER AND FLUX, CONNECTIONS

Solder & Soldering Flux



Low melting-point solder for easier soldering. Soldering flux includes brush. Use for easier soldering of copper sweat fittings.

p/n Description1325 Solder100 Soldering Flux (6 oz)

Cleaning Brush



For cleaning the inside of copper fittings.

p/n Description 378 Cleaning Brush, 3/4" 379 Cleaning Brush, 1"

Hex Bushing



Hex bushing with national pipe threads (NPT).

p/n Description
388 Hex Bushing, 1-1/4" x 3/4"
105 Hex Bushing, 1-1/2" x 3/4"
412 Hex Bushing, 1-1/4" x 1/2"
325 Hex Bushing, 3/4" x 1/2"
180 Hex Bushing, 3/4" x 1/8"
408 Hex Bushing, 1-1/2" x 1-1/4"

Brass Hex Bushing



Brass NPT reducing bushing

 p/n
 Description

 385
 Brass Hex Bushing, 1-1/2" x 3/4"

 3851
 Brass Hex Bushing, 1-1/4" x 3/4"

 3042
 Brass Hex Bushing, 1/2" x 1/8"

Brass Pipe Union, FIP



Suggested for use with plate-style heat exchanger installations.

p/nDescription5907Brass Pipe Union, 3/4"5908Brass Pipe Union, 1"5909Brass Pipe Union, 1-1/4"

Nipple



Extra-heavy male pipe thread (MPT) nipples. Nipple (p/n 118) is used with pumps and ball valves. Brass nipples must be used on stainless steel furnaces.

p/n Description
118 Nipple, 3/4" x close
409 Nipple, 1-1/4" x close
314 Nipple, 1-1/2" x close
533 Nipple, 3/4" x 2"
534 Nipple, 3/4" x 7"
535 Nipple, Brass, 3/4" x 2"
536 Nipple, Brass, 3/4" x 7"
11157 Nipple, Black, 1-1/4" x 3"

Brass Hose Bib



Brass hose bib, 3/4" MPT. Use brass cap (p/n 5348) with washer (p/n 5349) to cover end.

p/n
 199
 5349
 5348
 Cap, Brass, 3/4"

Tee, 3/4" NPT



Both Tees are 3/4" NPT. Black Tee (p/n 133) can be used for vent option near pump. Brass Tee (p/n 3850) can be used in domestic water situations.

p/n Description 133 Tee, Black, 3/4" NPT 3850 Tee, Brass, 3/4" NPT

Brass Tee, 3/4"



Brass Tee, 3/4" male x female x male. Mainly used for installing heat exchanger on water heater when push-fit fittings are used.

p/n Description 9624 Tee, Brass, 3/4"

Brass Offset Tee, 4"



Can be used in conjunction with the Temperature Gauge (p/n 174 or p/n 6054) for monitoring furnace supply water temperature, or may be used instead of Nipple (p/n 533) and 90° Street Elbow (p/n 274) on supply and/or return bung.

p/n Description 6764 Brass Offset Tee, 4"

Pipe Plug



Pipe Plug, MPT, black, unless noted.

 p/n
 Description

 331
 Pipe Plug, 3/4"

 574
 Pipe Plug, Brass 3/4"

 336
 Pipe Plug, 1-1/2"

 383
 Pipe Plug, 1-1/4"

 6557
 Pipe Plug, Brass 1/2"

Diverter Tee



The diverter tee is an excellent sweat fitting used mainly with fan-forced heaters.

p/n Description 6782 Diverter Tee, 1" x 1" x 1/2"

Monoflo Copper Tee



Used to divert water into fan-forced heaters and radiators.

p/n Description 4976 Copper Tee, 1" x 1" x 1/2"

45° Street Elbow



NPT 45° Street Elbow (black).

p/n Description 124 45° Street Elbow, 3/4"

90° Street Elbow



90° Street Elbow in different sizes.

 p/n
 Description

 411
 90° Street Elbow, 1-1/4"

 274
 90° Street Elbow, 3/4"

 126
 90° Street Elbow, Brass, 3/4"

Ball Valve



Brass FIP Ball Valve. The 3/4" Full Port Ball Valve (p/n 198) is used on both sides of the pump and on the furnace for each water line.

 p/n
 Description

 186
 Ball Valve, 1/2"

 198
 Ball Valve, 3/4" Full Port

 410
 Ball Valve, 1-1/4"

VALVES, MANIFOLDS, STRAINERS, CONNECTIONS, ADAPTERS

3-Way Valve




Manually operated, FIP, brass 3-Way Valve.

Description

3-Way Valve, Brass 3/4" FIP

3/4" Thermostatic Valve Kit




The Thermostatic Valve prevents the water temperature from dropping below the optimal operating temperature.

p/n Description

3/4" NPT Thermostatic Valve Kit

Mounting Bracket for 3/4" NPT Thermostatic Valve

1-1/4" Thermostatic Valve Kit



The Thermostatic Valve prevents the water temperature from dropping below the optimal operating temperature.

Description

1-1/4" NPT Thermostatic Valve Kit

1370 Mounting Bracket for 1-1/4" NPT Thermostatic Valve

Brass Swing Check Valve



Brass Swing Check Valve with FIP fittings prevents reverse circulation.

Description

Brass Swing Check Valve, 3/4" Brass Swing Check Valve, 1-1/4"

Cast Iron Manifold



Cast Iron Manifold features 1-1/2" FIP inlet and four 3/4" FIP outlets.

Description Cast Iron Manifold



Manifold features two 1-1/4" fittings, six 3/4" FIP fittings and two 1-1/4" bungs (one at each end) for large building system. Manifold measures 3" x 3" x 33-1/2".

Description

Y-Strainer



Y-Strainer with 0.20 mesh and FIP fittings. Recommended when installing plate-style heat exchangers. For 3/4" Y-Strainer, use 1/2" Brass Pipe Plug (p/n 6557) for cleanout port. For 1" Y-Strainer, use 3/4" Brass Pipe Plug (p/n 574) for cleanout port.

Description

Y-Strainer, 3/4" Brass

Y-Strainer, 1" Brass Y-Strainer, 1-1/4" Black

Hot Filter & Cartridge



Hot Filter (#10) with cartridge, 3/4" FIP fittings.

Description Hot Filter, 3/4" FIP

Cartridge, #10

Brass Coupling



Brass Coupling with 3/4" threaded fittings.

Description

Brass Coupling, 3/4" thread

Backflow Preventer



Used to protect supplies contamination.

Description 8364 Backflow Preventer, 3/4"

Purging and Filling Tee



Used to fill system and purge system of air.

DescriptionPurging and Filling Tee, 1"

Female Adapter, 3/4" Hose



4928 Brass Adapter, 3/4" female hose x 3/4" male pipe

Male Adapter, 3/4" Hose



Description

4929 Brass Adapter, 3/4" male hose x 3/4" male pipe

Brass Fittings for 1-1/4" PEX Pipe



Brass fittings for 1-1/4" PEX pipe. To ease installation, it is recommended that a heat gun be used on the 1-1/4" PEX pipe.

Description

380 381

Male Adapter, 1-1/4" barb x 1-1/4" MIP Brass Coupling, 1-1/4" barb x 1-1/4" barb Brass Elbow, 1-1/4" barb x 1-1/4" barb

PEX 1-1/4" Pipe



High-density, oxygen barrier, cross-link pipe, rated for 180°F. Each length should be insulated separately as two will not fit inside Central Therm insulation.

Description

PEX 1-1/4" Pipe, 150' PEX 1-1/4" Pipe, 300'

THERMOSTATS, TRANSFORMERS, AQUASTATS

Line Voltage Thermostat



Line Voltage Thermostat (120-volt) used to start the fan on forced-air systems.

Description 1267 Line Voltage Thermostat

Programmable 24-Volt Thermostat



Can be used in conjunction with zone valves, zone pumps and forced-air systems or used to operate 24-volt 3-way zone valves (requires 24volt transformer).

Description Programmable 24-Volt Thermostat

Single-stage, Non-programmable **24-Volt Thermostat**



Can be used in conjunction with zone valves, zone pumps and forced-air systems or used to operate 24-volt 3-way zone valves (requires 24volt transformer).

Description Non-programmable 24-Volt Thermostat

Multi-stage 24-Volt Thermostat



Large, easy-to-read screen allows homeowners to use one thermostat to control up to three stages of heat and two stages of cooling. Fully programmable. Must be installed and wired by a qualified service technician.

Description Multi-stage 24-Volt Thermostat


Plug-in Thermostat



Plug-in Thermostat, 13.5-amp rated, 110-Volt, is for operating fan.

Description Plug-in Thermostat

24-Volt Transformer



Used with 24-volt wall thermostat and 24-volt zone valves.

Description 24-Volt Transformer

3-Way Zone Valve, 24-Volt




Used to bypass water for radiant floor heat, baseboard heat, swimming pool heaters, etc. (requires 24-volt transformer).

Description

3-Way Zone Valve, 24-Volt, 1" sweat fittings 3-Way Zone Valve, 24-Volt, 3/4" sweat fittings 127

Replacement Head

2-Way Zone Valve, 24-Volt



Used to bypass water for radiant floor heat, baseboard heat, swimming pool heaters, etc. (requires 24-volt transformer).

Description

2-Way Zone Valve, 24-Volt, 1" sweat fittings 2-Way Zone Valve, 24-Volt, 3/4" sweat fittings

Replacement Head

Tempering Valve



Mixing valve for tempering hot water, with an adjustable temperature range between 120-160°F.

Tempering Valve, 1/2" sweat fittings

Tempering Valve, 3/4" sweat fittings

Thermostatic Mixing Valve



For controlling water temperature in various types of radiant heat systems. Temperature range 70°F -180°F (except p/n 306, range 70°F - 145°F). These are not anti-scald valves and are not intended to be used on water heaters with these temperature ranges.

Description

329

Thermostatic Mixing Valve, 1/2" NPT fittings Thermostatic Mixing Valve, 3/4" NPT fittings Thermostatic Mixing Valve, 1" NPT fittings

Thermostatic Mixing Valve



Designed specifically for water heaters, with a temperature range of 90°F - 130°F.

Description

Thermostatic Mixing Valve, 3/4" NPT fittings

Pool Aguastat



For controlling water temperature in pools, spas, etc., Pool Aquastat is immersible with a temperature range of 40-180°F in one-degree differential. With a pool or hot tub application, it is recommended to use a stainless steel well (p/n 1248). Well sold separately.

Description

Pool Aquastat, 1/2" NPT fitting Well, 1/2" NPT fitting

1247

1248 Well, SS, 1/2" NPT fitting

BASEBOARDS, COPPER CONNECTIONS

Baseboard Joiner



Used to cover joints in continuous lengths of baseboard.

p/n 230 Description Baseboard Joiner

Baseboard, Complete



Each baseboard includes heating element and cover. Rated 610 Btu/ft at 180°F water temperature. Flow rate of 4 gal/min, 3/4" copper sweat fittings. End caps, joiners and corners sold separately.

Description
Baseboard, Complete, 2' Baseboard, Complete, 3'
Baseboard, Complete, 4' 235 236 Baseboard, Complete, 5' Baseboard, Complete, 6' 237 238

Baseboard End Cap



Left or right Baseboard End Caps for radiant baseboard water heater.

Description p/n Baseboard End Cap, Left 233 Baseboard End Cap, Right

Baseboard Corners





Inside and outside Baseboard Corner covers for radiant baseboard water heater.

p/n Description Baseboard Corner, Inside 183 Baseboard Corner, Outside

90° Street Elbow, 1" Copper



90° street elbow with 1" female sweat fitting on one end and 1" male sweat fitting on the other.

Description 103 Street Elbow, 1"

Copper Coupling



Description 146

Copper Coupling, 3/4" sweat x 3/4" sweat fittings Copper Coupling, 1" sweat x 1" sweat fittings

Male Adapter, Copper



Description

Male Adapter, 3/4" sweat x 3/4" MIP fittings Male Adapter, 1" sweat x 1" MPT fittings

Female Adapter, Copper



Description

Female Adapter, 1" sweat x 3/4" FIP fittings Female Adapter, 3/4" sweat x 3/4" FIP fittings

Tee, Copper



Description

. 138 Tee, Copper Pipe, 1" x 1" x 1" sweat fittings Tee, Copper Pipe, 3/4" x 3/4" x 3/4" sweat fittings

Reducing Tee, Copper



Reducing Tee, 1-1/2" x 1" x 1" sweat fittings

Copper End Cap



Description

Copper End Cap, 1" sweat fitting

Vent Elbow, Copper



Description

Vent Elbow, 3/4" x 3/4" sweat fittings Vent Elbow, 1" x 1" sweat fittings


Drain Coupling, Copper



Description

Drain Coupling, Copper Pipe, 3/4" x 3/4" sweat

Reducer, Copper



Description

Reducer, Copper Pipe, 1" x 3/4" sweat fittings

90° Reducing Elbow, Copper



Description 90° Reducing Elbow, Copper Pipe, 1" x 3/4" sweat

90° Elbow, Copper



90° Elbow, Copper Pipe, 3/4" x 3/4" sweat fittings 90° Elbow, Copper Pipe, 1" x 1" sweat fittings

Sweat Ball Valve



Description

Sweat Ball Valve, 3/4" x 3/4" sweat fittings

PUSH-FIT FITTINGS

Push-fit Fittings

Push-fit Fittings are designed to simplify pipe installation. The fittings allow the user to connect pipe in seconds with relative ease.

- Instant push-fit connection for increased ease-of-use.
- No soldering, clamps, unions or glue required.
- Fits copper tubing and PEX piping and connects in any combination.

Coupling, Straight



p/n Description
Coupling, Straight, 1/2" x 1/2"
Coupling, Straight, 3/4" x 3/4"
Coupling, Straight, 1" x 1"

Coupling, Reducing



DescriptionCoupling, Reducing, 1" x 3/4"

Connector, Straight



p/n
610
Connector, Straight, 1/2" x 1/2" FNPT
611
Connector, Straight, 1" x 1" FNPT

Connector, Straight




p/n Description 612 Connector, Straight, 1" x 3/4" MNPT

Connector, Straight



p/n Description9264 Connector, Straight, 3/4" x 3/4" MIP

Elbow



p/n Description 613 Elbow, 1" x 1" 9265 Elbow, 3/4" x 3/4"

Tee



p/n Description Tee, 1" x 1" x 1"


Temperature Gauge Fitting



1/8" MPT Temperature Gauge (p/n 6054) installs on Temperature Gauge Fitting and fitting installs on push-fit fitting Tee (p/n 614).

p/n Description 1350 Temperature Gauge Fitting, 1" Push-fit x 1/8" NPT

Depth Gauge/Deburring Tool



Deburs pipe and used to mark pipe to indicate when the pipe is inserted completely into the fitting. One tool for 1/2", 3/4" and 1" pipe.

DescriptionDepth Gauge/Deburring Tool


Disconnect Clip



Used to disconnect push-fit fittings quickly and easily.

p/n Description 616 Disconnect Clip, 1/2" 617 Disconnect Clip, 3/4" 618 Disconnect Clip, 1"

Push-fit Fittings Water Heater Kit



Install on existing domestic water heater for thermal circulating heat transfer. Water-to-water heat exchanger is sold separately.

p/n Description9263 Push-fit Fittings Water Heater Kit

MAINTENANCE, REPLACEMENT AND OPTIONAL PRODUCTS

Water Softener Cartridge



For single use in filling water jacket, Water Softener Cartridge has 5,000 grains of removal capacity. For average water with 10 grains hardness, will treat 500 gallons water. May also be connected together to increase removal capacity.

Description 1310 Water Softener Cartridge

Corrosion Inhibitor Plus



Corrosion Inhibitor plus Polymer Solution helps protect exchangers and pumps against solids adhering to system parts. Refer to chart below for amounts used in each model furnace.

	Corrosion
Models	Inhibitor Amount
CL 4030	3/4 unit
CL 5036	1 unit
CL 6048	2 units
E-Classic 3200	2 units
E-Classic 2400	1-3/4 units
E-Classic 2300	2-1/2 units
E-Classic 1400	1 unit
Pallet Burner	3 units
CL 7260	4 units
Maxim M175, M250	1/2 unit

Description 1650 Corrosion Inhibitor Plus

Sludge Conditioner



Reduces mineral deposits in boiler side of waterto-water heat exchangers. Refer to chart below for amounts used in each model furnace.

Models	Sludge Conditioner Amount
CL 4030	1/2 gal.
CL 5036, CL 6048	1 gal.
CL 7260, Pallet Burner	2 gal.
Description	

p/n 166 Sludge Conditioner, 1 gal.

Water Test Kit



Water Test Kits and replacement items for testing your furnace water. Complete kits include pH test strips.

Description Water Test Kit, Complete 597

Water Test Kit, Complete, Anti-Freeze Compatible

153 Litmus Paper Permanganate 403 Sulfuric Acid

Decoiler



Useful when uncoiling and installing 1/2" tubing

Description 1323 Decoiler

Temperature Gauges



In-line, dial temperature gauge with 1/2" MPT (p/n 174) is optional for manifold, pool heater systems, etc. Gauge (p/n 6054) is 1/8" MPT, 1" diameter with 1" stem length, for use in tight areas.

Description Temp. Gauge, 1/8" MPT Temp. Gauge, 1/2" MPT

Tile Tape



Recommended for taping Central Therm Insulation joints after gluing with contact cement.

Description Tile Tape, roll

Grounding Rod Kit



Used to electrically ground the furnace.

6593 Grounding Rod Kit

Indoor Water Temperature Indicator Kit



Remote inline monitoring of water temperature (battery operated). Includes LCD, 75 feet of cord and probe. Dip switch can be set to either Fahrenheit or Celsius. NOTE: Black Tee (p/n 133) and Hex Bushing (p/n 180) are not included with the kit.

Description

Indoor Water Temperature Indicator Kit Tee, Black, 3/4" NPT 5052

133 Hex Bushing, 3/4" x 1/8" 180

Fan Center Relay



The Fan Center Relay is used to control a 110volt fan with a 24-volt thermostat.

Description Fan Center Relay

Fin Comb






Tool with six interchangeable heads for straightening fins on water-to-air heat exchangers. For all units with 8, 9, 10, 11, 12 and 14 fins per inch.

Description 5918 Fin Comb

MAINTENANCE, REPLACEMENT AND OPTIONAL PRODUCTS - CLASSIC AND PALLET BURNER



Used as a firebox maintenance tool, hoe comes with metal handle.

p/n Description 308 Hoe



Used for removing ashes from furnace.

p/n 299 Description Ash Shovel

Ash Rake

Long, metal-handled ash rake is used to pull coals forward and to stir ashes.

p/n Description Ash Rake

Ashtrol



Used as a furnace firebox pH modifier.

Description Ashtrol, 6.25 lbs

Vent Cap - Classic Models



Replacement Vent Cap for Classic outdoor furnaces helps prevent water loss through the vent pipe.

Description Vent Cap - Classic Models

Linkage



Linkage between the solenoid and damper control. Each linkage comes complete with cotter pins.

p/n 1266 Description Linkage, All Linkage Models Linkage, Wire Loop Models Spring-Assisted Linkage, All Linkage Models

Door Lock Kit



Prevents unauthorized access to the firebox.

Description

Door Lock Kit, for steel-door CL 7260 and Pallet

Door Lock Kit, for other Cam Loc models (including CL 7260 cast-iron door)

Draft Inducer




Bolts to existing draft hood (fan included). Must use 5-amp fuse. Do not use CL 7260 High-Output fan (p/n 5549) if a burner has been installed on the outdoor furnace.

Description Draft Inducer, Side Draft Draft Inducer, Ripple Front Door Draft Inducer, Flat Front Door Draft Inducer, CL 7260 Door

Draft Inducer, CL 7260 Dual Fuel Cast Door (w/ fuses)

Draft Inducer, CL 7260 High-Output 8563 Draft Inducer Fan (only)

Solenoid





Because damper control solenoids are not interchangeable, check measurement and application dates carefully. Solenoid (p/n 167) is for pre-June 2000 models. Solenoid (p/n 4184) if for models after June 2000.

Description Solenoid, 1-5/8" center-to-center bracket hole Solenoid, 1-3/8" center-to-center bracket hole

HeatTrac Controller Update Kits

Kits replace the HeatTrac Controller on furnaces. Kit (p/n 10904) is for furnaces with a hinged electrical box controller door. Kit (p/n 10902) is for furnaces with removable side panel cover.

Description

10904 HeatTrac Controller Update Kit (Models with Hinged Controller Door)

10902 HeatTrac Controller Update Kit (Models with Removable Side Panel Cover)

MAINTENANCE, REPLACEMENT AND OPTIONAL PRODUCTS - E-CLASSIC


Natural Gas Conversion Kit



Converts E-Classic 2300 models from propane to natural gas.

p/n Description 10598 Natural Gas Conversion Kit

Natural Gas Conversion Kit




Converts E-Classic 1400 and 2400 (kit p/n 10588) or E-Classic 3200 (kit p/n 11274) models from propane to natural gas.

NOTE: NG Conversion Kit only needed for gas burner kits sold before Dec. 1, 2010. After that date, complete gas burner kits for LP or NG are available.

Description

10588 Natural Gas Conversion Kit, E-Classic 1400/2400 31274 Natural Gas Conversion Kit, E-Classic 3200


Gas Burner Kit



Optional gas burner for E-Classic 1400 IR. 2400 IR and 3200 IR models. Available for either LP (propane) or NG (natural gas).

p/n Description 10275 LP Gas Burner Kit, E-Classic 1400 IR Models 10215 LP Gas Burner Kit, E-Classic 2400 IR Models 11295 LP Gas Burner Kit, E-Classic 3200 IR Models 10990 NG Gas Burner Kit, E-Classic 1400 IR Models 10991 NG Gas Burner Kit, E-Classic 2400 IR Models 11350 NG Gas Burner Kit, E-Classic 3200 IR Models


Pulse Timer Kit



Adds an air pulse timer relay to E-Classic 2300 wood only models for setting the duration of the air pulse and the length of time between them. For E-Classic 2300 wood only models with a serial number prior to E17808.

Description 10835 Pulse Timer Kit

Flue Brush & Handle



Used to clean the flue passageways. Flue Brush Kit (p/n 310) includes 311, 312 and handle. Not to be used for cleaning 6" or 8" chimney.

Description Flue Brush Kit

Cleaning Rod




Used to clean the firebox of E-Classic models.

Description

9439 Cleaning Rod, E-Classic

Wonder Bar



Used to clean the firebox of E-Classic models.

p/n Description 10691 Wonder Bar Description


Ash Shovel



Used to remove ash from E-Classic models.

Description 1970 Ash Shovel

2-Stage Gas Regulator Kit




Regulates the gas pressure in an LP tank. For all E-Classic or Maxim models.

Description

1930 2-Stage Gas Regulator Kit

CHIMNEY COMPONENTS - CLASSIC, E-CLASSIC AND PALLET BURNER

Classic Stainless Steel Chimney Sections



Type HT listed, factory-built, all stainless steel chimney section. If connecting to Chimney Extension (p/n 10508), use the 8" Chimney Band Clamp Kit (p/n 4518) at the joints. Sections are four feet long.


Description

Chimney Extension, 4'

Chimney Conversion Adapter, 8"

6726 Chimney Rain Cap, 8"

E-Classic Stainless Steel Chimney Section




Stainless steel 8" x 48" chimney currently shipped with E-Classic model outdoor furnaces. Have shipped with E-Classic 1400 since s/n E100299 and with E-Classic 2300 since s/n E17856. Compatible with Chimney Extension (p/n 6724). If connecting to Chimney Extension (p/n 6724), use the 8" Chimney Band Clamp Kit (p/n 4518) at the joints, not the Chimney Locking Band (p/n 10509). For outdoor applications only. Not to be used for venting of indoor heating appliances.

Description

10508 Chimney Extension, 4' 10509 Chimney Locking Band 10774 Chimney Rain Cap, 8"

Chimney Components



The Chimney Adapter Kit (p/n 10895) is used to convert CL 7260 and Pallet Burner models to the new chimney style (p/n 6724). The conversion will require three Chimney Extensions (p/n 6724).

Chimney Extension Components

Description

10895 Chimney Adapter Kit, 10" to 8", For Pallet Burner and CL 7260 models

6172 Elbow, 8", 45-degree 6173 Chimney Section, 8" x 24" for Tower Installation

Chimney Tee Restrictor Kit



Installed in chimney tee to lower the burn rate. For use only with CL 4030, CL 5036 and CL 6048 models.

Description 10970 Chimney Tee Restrictor Kit

Spark Arrestor



Stainless steel Spark Arrestor for the new-style chimney (p/n 6724).

Description Spark Arrestor

8" Chimney Band Clamp Kit



Reinforces strength between two sections of 8" chimney.

Description

p/n Description 4518 Chimney Band Clamp Kit, 8"

8" Chimney Base Brace Kit



Used to reinforce the chimney base when three or more chimney sections are used.

Description 4519 Chimney Base Brace Kit, 8"

Chimney Attachment Ring



Used with electrical conduit (not included) to reinforce chimney when five or more sections are used. Must be located directly below 8" Chimney Band Clamp (p/n 4518) to reduce stress on the joint.

Description Chimney Attachment Ring

Chimney Support Brace Kit



Reinforces strength of chimney support when several chimney sections are used. For use only with CL 4030. CL 5036 and CL 6048 models.

Description 4554 Chimney Support Brace Kit

Chimney Support Brace Kit



Reinforces strength of chimney support when several chimney sections are used. For use only with CL 7260 and Pallet Burner models.

p/n Description8402 Chimney Support Brace Kit

8" Chimney Guy-Wire Band Kit




Used to provide additional stability to chimneys in installations where property damage could occur within the fall zone of the chimney. Guy wire is not included in kit.

Description Chimney Guy-Wire Band Kit

MAINTENANCE, REPLACEMENT AND OPTIONAL PRODUCTS - MAXIM

Hopper Extension Kit




Increases hopper capacity by 3 bushels. For M175 models only.

Description

Hopper Extension Kit - Green Hopper Extension Kit - Terra Brown 4537

48-Bushel Hopper Kit




Increases fuel storage capacity for Maxim M175 and M250 models. Does not include auxiliary auger. If the 48-Bushel Hopper is to be located to the back of the outdoor furnace, use the 6' Auxiliary Auger Kit (p/n 9453). If it is located on the side of the outdoor furnace, use the 5-1/2' Auxiliary Auger Kit (p/n 9440). Available in either green and olive gray or terra brown and taupe to match the Maxim.

n/n Description

9760 48-Bushel Hopper Kit - Green and Olive Gray 48-Bushel Hopper Kit - Terra Brown and Taupe

Auxiliary Auger Kits for Maxim



Transfer augers for external hopper. Use 6' Auxiliary Auger Kit (p/n 9453) with the 48-Bushel Hopper Kit (p/n 9660 or 9760) when the hopper is located to the back of the furnace. Use 5-1/2' Auxiliary Auger Kit (p/n 9440) with the 48-Bushel Hopper Kit (p/n 9660 or 9760) when the hopper is located to the side of the furnace. The 8' Auxiliary Auger Kit (p/n 9454) will not work with the 48-Bushel Hopper.

NOTE: For furnaces with a serial number prior to M16073, the Power Cord (p/n 4177) must be purchased separately.


Description

9453 Auxiliary Auger Kit, 6 9440 Auxiliary Auger Kit, 5-1/2'

Auxiliary Auger Kit, 8'

Power Cord (see note above)


Hopper Vibrator Kit



Vibrator attaches to the side of the Maxim's integrated hopper to keep fuel from bridging. Templates provided for both M175 or M250 models.

Description 9691 Hopper Vibrator Kit

Auxiliary Auger Vibrator w/Timer Kit




Vibrator is installed on the auxiliary auger connected to an external 43-bushel or 48-bushel hopper. For use with Auxiliary Auger Kits 9440, 9453 and 9454 only. Vibration occurs based on timer setting.

Description

Auxiliary Auger Vibrator w/Timer Kit

Bag Holder Kit



Bag Holder attaches to the inside of the door of the 48-Bushel Hopper to support bag of fuel.

Description 9804 Bag Holder Kit

Aerator



The aerator supplies oxygen to the fuel for the most complete combustion.

Description

9707 Aerator, Cast 9710 Aerator, Stainless Steel

3/8" Cleaning Rod



Used to clean burn chamber.

Description

3/8" Cleaning Rod

MAINTENANCE, REPLACEMENT AND OPTIONAL PRODUCTS - MAXIM

Ash Scoop



4-Quart galvanized Ash Scoop is ideal for cleaning ashes from furnace.

p/n Description 315 Ash Scoop

Round Pipe Caps



p/n Description 332 3/4" Round Pipe Cap 333 1-1/4" Round Pipe Cap

24V Transformer



p/n Description 4045 24V Transformer

Propane Shut-off with Level Indicator



Used to monitor propane in a BBQ-style tank with Type 1 Acme threads connected to a Maxim furnace.

p/n Description 4220 Propane Shut-off with Level Indicator

Gas Hose w/Regulator



For use with M175 models only. No recommended for use in cold weather.

p/n Description5567 Gas Hose w/Regulator


High Pressure Gas Hose Adapter



For M250 models when attaching to an external propane tank larger than one pound.

DescriptionOcean Gas Hose Adapter, High Pressure


2-Stage Gas Regulator Kit



Regulates the gas pressure in an LP tank. For all E-Classic or Maxim models.

p/n Description 1930 2-Stage Gas Regulator Kit

Flue Brush & Handle



Used to clean the flue passageways. Flue Brush Kit (p/n 310) includes 311, 312 and handle. Not to be used for cleaning 6" or 8" chimney.

Description310 Flue Brush Kit

December 2010 19

CHIMNEY COMPONENTS - MAXIM

Maxim Stainless Steel Chimney Sections



Type HT listed, factory-built, all stainless steel 6" chimney section. Sections are four feet long.

p/n Description6797 Chimney Extension, 4'
4082 Chimney Rain Cap

Maxim Chimney Lengths



Three lengths of insulated chimney to obtain the required installation height. Features a 1/8-turn Twist-Lock assembly.

p/n Description
757 Chimney Length, 12"
758 Chimney Length, 24"
759 Chimney Length, 36"

Chimney Elbow






Allows an offset of a chimney to by-pass an obstacle. A maximum of two offsets (four elbows) is allowed.

p/n Description 760 Chimney Elbow, 15° 761 Chimney Elbow, 30°

Universal Roof Support



Adjustable to any roof pitch, designed to support chimney when chimney height exceeds loadbearing capacity of primary support.

p/n769DescriptionUniversal Roof Support


Universal Offset/Wall Support



Supports chimney above the offset of a vertical wall or as a wall support above the insulated tee.

p/n770DescriptionUniversal Offset/Wall Support

Radiation Shield



Used where the chimney passes through a ceiling or exterior opening when insulation is required. Must be used in combination with an attic radiation shield when passing through an attic.

p/n Description 764 Radiation Shield

Attic Radiation Shield



Protects combustible materials when a chimney passes through an attic. Used with radiation shield in applications when chimney passes through an attic.

p/n763DescriptionAttic Radiation Shield


Wall Radiation Shield



Designed for use when the chimney passes through a wall at an angle.

p/n Description
771 Wall Radiation Shield

Firestop



Used in combination with a radiation shield to provide additional protection when a chimney passes through combustible materials.

p/n Description 765 Firestop


Firestop



For use with radiation shield for offset installations.

p/n Description 751 Firestop

Flashing, Flat Roof




Seals a chimney length when passing through a flat roof. Includes storm collar.

p/n Description766 Flashing, Flat Roof

CHIMNEY COMPONENTS - MAXIM

Flashing, Adjustable Roof




Required for chimney installations passing through a roof peak. Available in two models for different roof pitches.

6" Chimney Cap

DescriptionFlashing, Adjustable Roof, 1/12 to 7/12 Pitch Flashing, Adjustable Roof, 8/12 to 12/12 Pitch 754 Flashing, Adjustable Roof, 12/12 to 21/12 Pitch 768






Cap for 6" chimney, with or without screen.

p/n Description

Chimney Cap, 6" w/screen Chimney Cap, 6" w/o screen


Reinforced Wall Band



Intended primarily to stabilize chimney along exterior wall in areas subject to high winds. Use of these bands at 10' intervals is recommended.

Description Reinforced Wall Band

Wall Band Extension



When used in combination with wall band, extends clearance between chimney's outer casing and the wall from 2" to 4".

Description Wall Band Extension

6" Chimney Band Clamp Kit




Reinforces strength between two sections of 6" chimney.

Description

9535 Chimney Band Clamp Kit, 6"


Chimney Attachment Ring



For use on an interior or exterior wall, stabilizes chimney while providing required clearance from combustible surface. Use of Chimney Attachment Rings at maximum intervals of 8' is recommended.

Description Chimney Attachment Ring


Universal Roof Brace



For stabilizing a chimney extending from 5' to 9' beyond the roof, or when chimney is exposed to high winds. Includes tightening collar and adjustable legs.

Description p/n Universal Roof Brace

Guy-Wire Band



Attached to the outer casing of the chimney to three guy-wires (not included). Recommended for chimneys exceeding the roof by 5' to 13' maximum.

Description Guy-Wire Band

NUMERICAL PARTS LIST

15	100	Soldering Flux (6 oz)9	293	PEX Hanger, 1/2"	610	Connector, Straight, 1/2" x 1/2" FNPT
September Control Ford Proposed Total Control Ford Proposed Total Control Ford Proposed Total Control Ford Proposed Pro		Hot Filter, 3/4" FIP	295	PEX Hanger, 1"		Connector, Straight, 1" x 1" FNPT
1965 Heds Gusting 1-1/2* x3" 3 30 An Risea. 10 10 10 10 10 10 10 1	103	Street Elbow, 1"12	297	Ashtrol, 6.25 lbs	613	Elbow, 1" x 1"
166 Heafe Exchanger Coll 10th Bits 2 3 30 Art Heafed Cathers (10th 440 Bits) 1 1 1 1 1 1 1 1 1		Hex Bushing, 1-1/2" x 3/4"				Depth Gauge/Deburring Tool
Mode Exchange Col. 128 Bb. straight outside 2 305 Thermostatic Mining Valva, 127 PFT fillings 1 618 Disconnect City 1 2 2 3 5 1 2 3 5 1 2 3 5 1 3 5 2 3 3 3 3 3 3 3 3 3		Heat Exchanger Coil. 100k Btu				Disconnect Clip 1/2" 13
Best Enchanger Cod, 19th But. 2, 3		Heat Exchanger Coil, 125k Btu, straight outlets 2				Disconnect Clip, 1"
Heat Eschange Cod 1286 Bits				Hoe		2-Way Zone Valve, 24-Volt, 1" sweat fittings 11
Part Ebox 1 1 1 1 1 1 1 1 1		Heat Exchanger Coil, 185k Btu		Nipple, 1-1/2" x close		Draft Inducer, Flat Front Door
131 Saylacament Head 1 3149 Healt Exchanging, Water-D-Water Double Wall, 47 3 75 Freeding 1 32 9 1 32 9 1 32 9 1 32 9 1 32 9 1 32 9 1 32 9 1 32 3 3 3 3 3 3 3 3				Ash Scoop		Heat Exchanger Coil, 125k Btu, 90° outlets
Mais Adopter, 34f weet 34f MIP Fittings	113	Replacement Head	318	Heat Exchanger, Water-to-Water, Double Wall, 42" 8	751	Firestop
Farnel Adaptic, 34" week 3.94" Fill fillings 12 322 Fan 2 757 Chimmey Length, 12" 2 758 Chimmey Length, 12" 2 759 Chimmey Elbow, 15" 2 759 Chimm						Chimney Cap, 6" w/o screen
19 Pump Flamps (M. 34) 19 19 19 19 19 19 19 1	117	Female Adapter, 3/4" sweat x 3/4" FIP fittings 12	322	Fan	757	Chimney Length 12" 20
Hes Bushing, 34" x 10" 37 38 18 38 38 39 39 39 39 39 3		Nipple, 3/4" x close				Chimney Length, 36"
24		Male Adapter, 1" sweat x 1" MPT fittings12	325	Hex Bushing, 3/4" x 1/2"9		Chimney Flhow 15° 20
24		1" x 3/4" sweat fittings	327	Thermostatic Mixing Valve, 3/4" NPT fittings 11	763	Attic Radiation Shield
27 3.7 3.7 3.7 3.7 3.7 3.7 3.7 3.7 3.7 3.8 3.7 3.8 3.7 3.8 3.7 3.8 3.7 3.8 3.7 3.8 3.7 3.8 3.7 3.8 3.7 3.8 3.7 3.8 3.7 3.8 3.7 3.8 3.7 3.8 3.7 3.8		45° Street Elbow, 3/4"		Thermostatic Mixing Valve, 1" NPT fittings		Radiation Shield
Pales Exchanger, MPN 5 x 12-50, 1-14* Pott.	127	3-Way Zone Valve, 24-Volt, 3/4" sweat fittings 11	331	Pipe Plug, 3/4"	766	Flashing, Flat Roof
133 Fee, Black, 34" NPT 9, 14 334 12" 13" 13" 13" 14" 15" 14" 15" 14" 15" 14" 15" 14" 15"		Plate Exchanger, MPN 5 x 12-40, 1-1/4" Port 7 Plate Exchanger, MPN 5 x 12-50, 1-1/4" Port		3/4" Round Pipe Cap		Flashing, Adjustable Roof, 1/12 to 7/12 Pitch 21 Flashing, Adjustable Roof, 12/12 to 21/12 Pitch 21
138 Tee, Copper Pipe, 1* 1* x* sweet fittings, 12 12 12 12 12 12 13 13	133	Tee, Black, 3/4" NPT9, 14	336	Pipe Plug, 1-1/2"9	769	Universal Roof Support 20
140		Tee, Copper Pipe, 1" x 1" x 1" sweat fittings 12		Louvers, fit Heat Exchanger Coil (p/n 108)3		Wall Radiation Shield
146 Copper Coupling, 1 'sweet 1's weet fittings 12 372	140	Tempering Valve, 3/4" sweat fittings	355	Louvers, fit Heat Exchanger Coil (p/n 106)3	772	Reinforced Wall Band
147 Copper Coupling, 1's weet x' 1's weet fittings. 12 373 Drain Coupling, Copper Pipe, 3 374 341's weet fittings. 12 775 Copper End Cap, 1's weet fittings. 13 376 Copper End Cap, 1's weet fitting	146	Copper Coupling, 3/4" sweat x 3/4" sweat fittings 12	372	Vent Elbow, 3/4" x 3/4" sweat fittings	774	Chimney Attachment Ring
Shell & Tube, 27		Copper Coupling, 1" sweat x 1" sweat fittings 12	373	Drain Coupling, Copper Pipe, 3/4" x 3/4" sweat fittings		Universal Roof Brace
Shell & Tube, 60"		Shell & Tube. 27"		Copper End Cap, 1" sweat fitting	777	Chimney Cap, 6" w/screen
Lifmus Paper 14 380 Male Adapter, 1-14" barb x 1-14" barb x 1-14" barb x 1-14" barb x 1-16" bar 15 Familiades 161 Familiades 162 Familiades 162 Familiades 162 Familiades 163 Familiades 163 Familiades 163 Familiades 164	151	water-to-Water Heat Exchanger, Shell & Tube, 60"		Cleaning Brush. 1"9		Chimney Guy-Wire Band Kit
163 Tempering Valve, 1/2" sweal fittings 11 382 Brass Elbow, "1-14" barb x 1-14" barb 10 1097 Universal Heat Exchanger Mounting Kit.		Litmus Paper14	380	Male Adapter, 1-1/4" barb x 1-1/4" MIP10	849	Transition
Female Adapter, 1*sweat x3/4" [Pf fittings. 12] 333 Pipe Plug, 1-1/4" 9 1247 Well, 1/2" NPT fitting.		Tempering Valve, 1/2" sweat fittings		Brass Coupling, 1-1/4" barb x 1-1/4" barb/, 10 Brass Elbow, 1-1/4" barb x 1-1/4" barb10		Universal Heat Exchanger Mounting Kit
Fig. Solenoid, 1-5/8' center-to-center bracket hole 15 366 PEX 1-1/4" Pipe, 300" 10 1266 Linkage, All Linkage Models 170 Replacement Cartridge, 009 Series Pumps 5 395 395 Manifold 10 1270 Linkage, Wire Loop Models 1717 1727 1727 Linkage, Wire Loop Models 1717 1727	164	Female Adapter, 1" sweat x 3/4" FIP fittings 12	383	Pipe Plug, 1-1/4"9		Well, 1/2" NPT fitting
			386	PEX 1-1/4" Pipe, 300'		Linkage, All Linkage Models
Replacement Cartridge, 009 Series Pumps				Hex Bushing, 1-1/4" x 3/4"		Line Voltage Thermostat
Temp. Gauge, 1/2" MPT	172	Replacement Cartridge, 009 Series Pumps 5	396	Spark Arrestor	1272	Pump Flange Kit, 1-1/4"
Tago 006 Pump		Taco 009 Pump				Fan Motor
177 Heat Exchanger, Water-to-Water, Shells Tube, 48° 10° 10° 10° 10° 110° 10° 110° 10° 110°	175	Taco 006 Pump5	404	Sulfuric Acid		5 per bag
Shell & Tube, 48" Shell & Shel		Heat Exchanger, Water-to-Water,		Cast Iron Manifold	1303	20 per bag
Replacement Cartridge, 014 Series Pumps 5 410 Ball Valve, 1-1/4" 9 1312 Central PEX 1" Pipe, 200'	170	Shell & Tube, 48"		Hex Bushing, 1-1/2" x 1-1/4"9		Water Softener Cartridge
Baseboard Corner, Outside	179	Replacement Cartridge, 014 Series Pumps 5		Ball Valve 1-1/4" 9	1312	Central PEX 1" Pipe. 200'
Baseboard Corner, Outside				90° Street Elbow, 1-1/4"		Central PEX 1" Pipe, 300'
188 24-Volt Transformer.	183	Baseboard Corner, Outside	413	Taco 007 Priority Pump5	1320	Central PEX 1/2" Pipe, 300' 6
191 Pool Aquastat, 1/2" NPT fitting		Ball Valve, 1/2"				Central PEX 1/2" Pipe, 500'
195 PEX Pipe Gulter 6 515 Fan Center Relay 14 1325 Solder	191	Pool Aquastat, 1/2" NPT fitting	500	Draft Inducer, Ripple Front Door	1323	Decoiler
198 Ball Valve, 3/4" Full Port	195	PEX Pipe Čutter	515	Fan Center Relay	1325	Solder
200 Sweat Ball Valve, 3/4" x 3/4" sweat fittings. 12 526 Central Therm Sleeve, 300". 7 7 7 7 7 7 7 7 7 7		Ball Valve, 3/4" Full Port		Central Therm Sleeve, 100'		Manifold w/Valves. 3-Loop
202 Cartridge, #10	200	Sweat Ball Valve, 3/4" x 3/4" sweat fittings 12	526	Central Therm Sleeve 300' 7	1331	PEX Adapter, 1" PEX x 1" sweat fittings 6
208 Blower & Motor, 1-hp. 3 535 Nipple, Brass, 3/4" x 2" 9 1335 PEX Crimp Ring, 1" 219 Replacement Cartridge, 011 Series Pumps 5 536 Nipple, Brass, 3/4" x 7" 9 1335 PEX Crimp Ring, 1" 224 "Free Floating" Flange Kit, 3/4" 5 537 Door Lock Kit, for other Cam Loc models 1337 PEX Adapter, 1/2" PEX x 3/4" MIP fittings 1338 PEX Crimp Ring, 1" 1334 PEX Adapter, 1/2" PEX x 1/2" sweat fittings 1337 PEX Adapter, 1/2" PEX x 1/2" sweat fittings 1338 PEX Crimp Ring, 1" 1334 PEX Adapter, 1/2" PEX x 1/2" sweat fittings 1337 PEX Adapter, 1/2" PEX x 1/2" sweat fittings 1338 PEX Crimp Ring, 1" 1338 PEX Crimp Ring, 1" 1339 PEX Crimp Ring, 1" 1339 PEX Adapter, 1/2" PEX x 1/2" sweat fittings 1338 PEX Crimp Ring, 1" 1339 PEX Crimp Ring, 1/2" 1339 PEX Cr				Central Therm Sleeve, 500'		PEX Tee, 1"
222 Replacement Cartridge, 006 Series Pumps 5 537 Door Look Kit, for other Cam Loc models 1337 PEX Adapter, 1/2" PEX x 1/2" sweat fittings 1338 PEX Tee, 1/2" 1338 PEX Tee, 1/2" 1339 PEX Coupling, 1/2" 1339 PEX Coupling, 1/2" 1339 PEX Tee, 1/2" 1340 PEX 90' Elbow, 1/2" 1340 PEX 90' Elbow, 1/2" 1340 PEX Adapter, 1/2" PEX x 1/2" MIP fittings 1	203	Blower & Motor, 1/15-hp	534	Nipple. 3/4" x 7"9	1334	PEX 90° Elbow, 1"
222 Replacement Cartridge, 006 Series Pumps 5 537 Door Look Kit, for other Cam Loc models 1337 PEX Adapter, 1/2" PEX x 1/2" sweat fittings 1338 PEX Tee, 1/2" 1338 PEX Tee, 1/2" 1339 PEX Coupling, 1/2" 1339 PEX Coupling, 1/2" 1339 PEX Tee, 1/2" 1340 PEX 90' Elbow, 1/2" 1340 PEX 90' Elbow, 1/2" 1340 PEX Adapter, 1/2" PEX x 1/2" MIP fittings 1	219	Replacement Cartridge, 011 Series Pumps5		Nipple, Brass, 3/4 x 2	1336	PEX Adapter, 1/2" PEX x 3/4" MIP fittings 6
225 Isolation Flange Kit, 1-1/4" 5 542 Ö-Ring Set 5 526 Fower Supply Cord, 32" 5 556 Fower Supply Cord, 32" 5 5 556 Fower Supply Cord, 32" 5 5 757 Fower Supply Cord, 32" 5 757 Fower Supply Cord, 34" 75 75 75 75 75 75 75 7	222	Replacement Cartridge, 006 Series Pumps 5	537	Door Lock Kit, for other Cam Loc models		PEX Adapter 1/2" PEX x 1/2" sweat fittings 6
230 Baseboard Joiner 12 12 1341 1341 PEX Adapter, 1/2" PEX x 1/2" MIP fittings 12 1342 PEX Crimp Ring, 1/2" 1343 PEX Adapter, 1/2" PEX x 1/2" RIP fittings 1348 PEX Adapter, 1/2" PEX x 1/2" RIP fittings 1349 PEX Crimp Ring, 1/2" 1349 PEX Crimp Ring, 1/2" 1349 PEX Crimp Ring, 1/2" PEX x 1/2" RIP fittings 1349 PEX Crimp Ring, 1/2" PEX x 1/2" RIP fittings 1349 PEX Adapter, 1/2" PEX x 1/2" RIP fittings 1348 PEX Adapter, 1/2" PEX x 1/2" RIP fittings 1349 PEX Ad	225	Isolation Flange Kit, 1-1/4"		O-Ring Set	1339	PEX Coupling, 1/2"
231 Reducer, Copper Pipe, 1" x 3/4" sweat fittings 12 573 Y-Strainer, 1" Brass. 10 1342 PEX Crimp Ring, 1/2" 1/2" PEX x 1/2" FIP fittings 12 1348 PEX Adapter, 1/2" PEX x 1/2" FIP fittings 1349 PEX Adapter, 1/2" PEX x 1/2" PEX x 1/2" PEX x 1/2" PEX Adapter, 1/2" PEX x 1/2" PEX x 1/2" PEX Adapter, 1/2" PEX x 1/2" PEX x 1/2" PEX x 1/2" PEX Adapter, 1/2" PEX x	226 230	Isolation Flange with Drain Valve, 3/4"		Power Supply Cord, 32"		PFX Adapter 1/2" PFX x 1/2" MIP fittings 6
233 Baseboard End Cap, Right 12 587 Multi-stage 24-Volt Thermostat 11 1349 Manifold w/Valves, 24-Lopp	231	Reducer, Copper Pipe, 1" x 3/4" sweat fittings 12	573	Y-Strainer, 1" Brass	1342	PEX Crimp Ring, 1/2"
234 Baseboard, Complete, 2 12 588 Programmable 24-Volt Thermostat 11 1350 Temperature Gauge Fitting, 1" Push-fit x 1/8" N	233	Baseboard End Cap, Leπ		Multi-stage 24-Volt Thermostat		Manifold w/Valves, 2-Loop
236 Baseboard, Complete, 4'	234	Baseboard, Complete, 2'	588	Programmable 24-Volt Thermostat	1350	Temperature Gauge Fitting, 1" Push-fit x 1/8" NPT 13
237 Baseboard, Complete, 5'. .12 600 Panel Radiator, 32" x 16" .8 1366 Universal Pump Wall Mount Kit. 238 Baseboard, Complete, 6'. .12 601 Panel Radiator, 35-1/2" x 24" .8 1370 Mounting Bracket for 1-1/4" NPT 241 Central Therm Insulation, 8'. .7 602 Panel Radiator, 51-1/2" x 24" .8 Thermostatic Valve 242 Central Therm Insulation, 4'. .7 603 Panel Radiator, 55-1/4" x 24" .8 1544 3/4" NPT Thermostatic Valve Kit 251 Tile Tape, roll. .7 603 TRV II Valve Body and Head, 1/2" Vertical .8 1621 1-1/4" NPT Thermostatic Valve Kit 255 Tape Conper Pine, 3/4" x 3/4"	236	Baseboard, Complete, 4'	597	Water Test Kit, Complete, Anti-Freeze Compatible 14		Thermostatic Valve
241 Central Therm Insulation, 8' .7 602 Panel Radiator, 51-1/2" x 24" .8 Thermostatic Valve 242 Central Therm Insulation, 4' .7 603 Panel Radiator, 55-1/4" x 24" .8 1544 3/4" NPT Thermostatic Valve Kit 251 Tile Tape, roll .14 604 TRV II Valve Body with No Cap .8 1621 1-1/4" NPT Thermostatic Valve Kit 255 Tee Copper Pine 3/4" x 3/4" x 3/4" sweat fittings 12 .605 LKD Valve Body with No Cap .660 .660 LKD Valve Body with No Cap .660<	237			Panel Radiator, 32" x 16"		Universal Pump Wall Mount Kit
242 Central Therm Insulation, 4'	241	Central Therm Insulation, 8'	602	Panel Radiator, 51-1/2" x 24"		Thermostatic Valve
255 Tee Conner Pine 3/4" x 3/4" x 3/4" sweat fittings 12 605 LKD Valve Rody with No Can	242 251			Panel Radiator. 55-1/4" x 24"		3/4" NPT Thermostatic Valve Kit
■ 774 YU Street Floom 374" Y ■ 177" Preset Flow Rate X ■ 1694 Y-Strainer 1-174" Rlack	255	Tee, Copper Pipe, 3/4" x 3/4" x 3/4" sweat fittings 12		LKD Valve Body with No Can	1650	Corrosion Inhibitor Plus 14
■ 276 90° Elbow, Copper Pipe, 3/4" x 3/4" sweat fittings 12 ■ 606 Coupling, Straight, 1/2" x 1/2"		90° Elbow, Copper Pipe, 3/4" x 3/4" sweat fittings 12	606	Coupling, Straight, 1/2" x 1/2"	1694 1695	Y-Strainer, 3/4" Brass
277 90° Elbow, Copper Pipe, 1" x 1" sweat fittings 12 607 Coupling, Straight, 3/4" x 3/4" 1880 Manifold w/o Valves, 2-Loop	277	90° Elbow, Copper Pipe, 1" x 1" sweat fittings 12	607	Coupling, Straight, 3/4" x 3/4"	1880	Manifold w/o Valves, 2-Loop
286 Automatic Vent Valve .8 608 Coupling, Straight, 1" x 1". .13 1885 Manifold w/o Valves, 3-Loop. 287 Heat Exchanger Coil, 50k Btu. .2 609 Coupling, Reducing, 1" x 3/4". .13 1910 Fan Convector, Corner, 7k Btu	287	Heat Exchanger Coil, 50k Btu		Coupling, Reducing, 1" x 3/4"		Fan Convector, Corner, 7k Btu

NUMERICAL PARTS LIST (cont.) Auxiliary Auger Kit, 6' Auxiliary Auger Kit, 8' 18 Auxiliary Auger Kit, 8' 18 Auxiliary Auger Vibrator w/Timer Kit 18 Chimney Band Clamp Kit, 6" 21 Heat Exchanger Mounting Kit 8 Tee, Brass, 3/4" 9 9458 5744 48-Bushel Hopper Kit - Terra Brown and Taupe 18 Fin Comb. 14 Cinch Tool 6 PEX Stainless Steel Clamp Crimp Ring, 1" 6 PEX Stainless Steel Clamp Crimp Ring, 1/2" 6 PEX Stainless Steel Clamp Crimp Ring, 1/2" 6 Central Boiler Clamp, 1" 6 Temp. Gauge, 1/8" MPT 14 Elbow, 8", 45-degree 17 Chimney Section, 8" x 24" for Tower Installation 17 Draft Inducer, CL 7260 Door 15 Pioe Plug. Brass 1/2" 9 Bag Holder Kit..... LP Gas Burner Kit, E-Classic 2400 IR Models 16 Chimney Extension, 4' 17 Chimney Locking Band 17 Little Constraint Kit F Classic 1400 (2400) 16 6172 6173 10509 Pipe Plug, Brass 1/2" 9 Draft Inducer, CL 7260 Dual Fuel Cast Door (Wfuses) 15 Grounding Rod Kit. 14 Female Adapter, 1/2" barb x 1/2" sweat fittings 6 Chimney Extension, 4' 17 Chimney Rain Cap, 8" 17 Chimney Conversion Adapter, 8" 17 Brass Offset Tee, 4" 9 Myson Whispa II Kickspace 9000 Fan Convector 4 Myson Lo-Line RC 6-4 Fan Convector 4 Myson Hi-Line HL 7-4 Fan Convector 4 Myson Slim-Line RC Fan Convector 4 HeatTrac Controller Update Kit (Models with Hinged Controller Door). 15 Chimney Tee Restrictor Kit 17 NG Gas Burner Kit, E-Classic 1400 IR Models. 16 NG Gas Burner Kit, E-Classic 2400 IR Models. 16 Nicola Plate 14 (41) HeatTrac Controller Update Kit Myson Whispa II Kickspace 5000 Fan Convector. 4 Diverter Tee, 1" x 1" x 1/2" . 9 Chimney Extension, 4' 20 Myson Whispa III Fan Convector 4 Spring-Assisted Linkage, All Linkage Models 15 Backflow Preventer, 3/4" 10 Chimney Support Brace Kit. 17 Proft Indiverse Fan (only) 15 6797 NG Gas Burner Kit, E-Classic 3200 IR Models. 16 Draft Inducer Fan (only) 15 Push-fit Fittings Water Heater Kit 13 Connector, Straight, 3/4" x 3/4" MIP 13 Elbow, 3/4" x 3/4" 13 Gas Hose Adapter, High Pressure 19

December 2010 23

SAMPLE PARTS LIST and ORDER LIST

Sample Parts List for Forced-Air Heating System

QTY.	P/N	DESCRIPTION
1		Central Boiler Outdoor Wood Furnace
1	107	Heat Exchanger Coil, 125k Btu
1	591	Side-Arm Heat Exchanger Kit
1	2053	Fittings Kit
1	171	Taco 007 Pump
1	224	Isolation Flange Kit, 3/4"
1	190	24-Volt Thermostat
1	198	Ball Valve, 3/4"
1	118	Nipple, 3/4" x close
1	296	Brass Swing Check Valve, 3/4"
6	1330	PEX Adapter, 1" PEX x 3/4" MIP
6	1333	PEX Coupling, 1"
6	1334	PEX 90° Elbow, 1"
30	5926	PEX Stainless Steel Clamp Crimp Ring, 1"
1	2441	100' ThermoPEX Pipe, 1"
1	1302	Central PEX 1" Pipe, five 10' straight sections
1	2443	ThermoPEX Cap, 1"
1	6593	Grounding Rod Kit
1	556	Power Supply Cord, 32"
2	1650	Corrosion Inhibitor Plus
1	297	Ashtrol, 6.25 lb
1	299	Ash Shovel
1	300	Ash Rake
1	308	Hoe

Rev. 12/2010

Sample Parts List for Additional Buildings

QTY.	P/N	DESCRIPTION
1	323	Transition
1	322	Fan
1	106	Heat Exchanger Coil, 100k Btu
1	171	Taco 007 Pump
1	224	Isolation Flange Kit, 3/4"
1	160	Line Voltage Thermostat
1	198	Ball Valve, 3/4"
4	1334	PEX 90° Elbow, 1"
8	1330	PEX Adapter, 1" PEX x 3/4" MIP
30	5926	PEX Stainless Steel Clamp Crimp Ring, 1"
1	199	Brass Hose Bib, 3/4" MPT
1	133	Black Tee, 3/4" NPT
1	556	Power Supply Cord, 32"
1	296	Brass Swing Check Valve, 3/4"
1	118	Nipple, 3/4" x close
2	6764	Brass Offset Tee, 4"

Rev. 12/2010

PARTS LIST and ORDER LIST

Parts List

QTY.	P/N	DESCRIPTION
Q11.	F/IN	DESCRIPTION

December 2010 25